

25
27

MULTIMETER

Service Manual

FLUKE




Figure 5-1. A1 Main PCB and A2 Digital PCB Schematic (cont)

25 27 MULTIMETER

Service Manual

PN 738138
 October 1984 Rev. 3, 11/94
 ©1984, 1992, 1994 Fluke Corporation. All rights reserved. Printed in U.S.A.
 All product names are trademarks of their respective companies.

FLUKE®


Pozidriv is a registered trademark of Phillips Screw Company.
 Teflon is a registered trademark of E.E. Dupont DeNemours & Co.

NOTES: UNLESS OTHERWISE SPECIFIED—

1. ALL RESISTANCE VALUES IN OHMS.
2. ALL CAPACITANCE VALUES IN μ F.
3. C5 IS FACTORY SELECTED (MAY NOT BE USED).
4. ALL RESISTORS ARE CARBON COMP OR (CARBON FILM, 1/4 W, \pm 5%
5. ALL WIRE WOUND RESISTORS CODED "WW"
6. CAPACITOR CODE :
 M MYLAR + ELECTROLYTIC
 C CERAMIC AL ALUMINUM
 PP POLYPROPYLENE T TANTALUM
 PC POLYCARBONATE TEF TEFロン
7. RESISTORS \leq 1% TOLERANCE ARE METAL FILM OR WIRE WOUND.
8. ALL MF RESISTORS ARE 1/8W, \pm 1%.
- 9.
10. S1F IS UPPER ROTARY SWITCH, FRONT SECTION
 S2F IS LOWER ROTARY SWITCH, FRONT SECTION.
 S1R IS UPPER ROTARY SWITCH, REAR SECTION.
 S2R IS LOWER ROTARY SWITCH, REAR SECTION.

REF DESIGNATIONS	
LAST NO. USED	NOT USED
C51	C15, 24, 25, 14, 27, 28, 29, 35,
Q15	Q3-9
R42	R11, 17, 21, 22, 34
S6	S4, 5,
U7	U4, 5, 6
W3	W2
AR1, BT1, CR7, F3, L5, J8 L1, RJS, RT2, VR1, Y1, Z1	

- 11.
12. THIS DRAWING IS USED IN CONJUNCTION WITH A MSHA APPROVED PRODUCT. CHANGES MUST BE APPROVED BY FLUKE PRODUCT SAFETY ENGINEERING AND MSHA.
- 13.
14. R42 IS OPTIONAL AND IS INSTALLED WHEN NECESSARY TO ENSURE PROPER OSCILLATOR STARTUP.



Fluke Corporation
 P.O. Box 9090
 Everett, WA
 98206-9090

Fluke Europe B.V.
 P.O. Box 1186
 5602 B.D.
 Eindhoven
 The Netherlands

Figure 5-1. A1 Main PCB and A2 Digital PCB Schematic





Table of Contents

SECTION	TITLE	PAGE
1	INTRODUCTION	1-1
1-1.	INTRODUCTION	1-1
1-2.	SPECIFICATIONS	1-1
1-3.	OPERATING INSTRUCTIONS	1-1
2	THEORY OF OPERATION	2-1
2-1.	INTRODUCTION	2-1
2-2.	FUNCTIONAL DESCRIPTION	2-1
2-3.	BLOCK DIAGRAM DESCRIPTION	2-1
2-4.	Input Overload Protection	2-1
2-5.	Function Switching Circuits	2-1
2-6.	Signal Conditioning Circuits	2-2
2-7.	Custom Analog IC (U1)	2-2
2-8.	Peripherals to U1	2-4
2-9.	Microcomputer Control	2-4
2-10.	Display	2-5
3	MAINTENANCE	3-1
3-1.	INTRODUCTION	3-1
3-2.	SERVICE INFORMATION	3-1
3-3.	OPERATOR MAINTENANCE	3-2
3-4.	Battery Replacement	3-2
3-5.	Fuse Test	3-2
3-6.	Fuse Replacement	3-2
3-7.	GENERAL MAINTENANCE INFORMATION	3-3
3-8.	Handling Precautions For Static-Sensitive Devices	3-3
3-9.	Disassembly	3-5
3-10.	Reassembly	3-5
3-11.	Cleaning	3-6
3-12.	PERFORMANCE TEST	3-6
3-13.	Display Test	3-7
3-14.	Voltage Functions Performance Verification	3-7
3-15.	AC and DC Current Performance Verification	3-7
3-16.	Ohms Function Performance Verification	3-8
3-17.	Diode Test Performance Verification	3-8

SECTION	TITLE	PAGE
3-18.	CALIBRATION ADJUSTMENT	3-9
3-19.	Calibration Preparation	3-9
3-20.	DC Voltage Calibration	3-9
3-21.	AC Voltage Calibration	3-10
3-22.	TROUBLESHOOTING	3-10
3-23.	Power-Up Self Test	3-10
3-24.	Overall System Check	3-10
3-25.	DC Voltage Signal Tracing	3-11
3-26.	Fault Diagnosis Guide	3-12
4	LIST OF REPLACEABLE PARTS	4-1
	TABLE OF CONTENTS	4-1
4-1.	INTRODUCTION	4-2
4-2.	HOW TO OBTAIN PARTS	4-2
4-3.	MANUAL STATUS INFORMATION	4-2
4-4.	NEWER INSTRUMENTS	4-2
4-5	SERVICE CENTERS	4-9
5	SCHEMATIC DIAGRAMS	5-1

Section 5 Schematic Diagrams

FIGURE	TITLE	PAGE
5-1.	A1 Main PCB and A2 Digital PCB Schematic	5-2

SERVICE CENTERS (cont)

Colombia
Sistemas E Instrumentacion, Ltda.
Carrera 21, NO. 39A-21, OF. 101
Ap. Aereo 29583
Bogota
TEL: 57 287-5424

Denmark
Phillips Eleltronix Systemer A/S
Strandlodsvej 4B
DK 2300
Copenhagen
TEL: 45 32 882531
TLX: 31201 phil dk

Ecuador
Proteco Coasin Cia., Ltda.
P.O. Box 228-A
Ave. 12 de Octubre
2285 y Orellana
Quito
TEL: 593 2 529684
TLX: (393) 22085 ESIND

Egypt
Phillips Egypt
10, Abdel Rahman el Rafei st.
el. Mohandessin
P.O. Box 242
Dokki Cairo
TEL: 20 2 490922
TLX: 22816 phegy un

England
Phillips Scientific
Test & Measuring Division
Colonial Way
Watford
Hertfordshire WD2 4TT
TEL: 44 923-240511
TLX: 851 934583 PHI TMD

Federal Republic of Germany
Phillips GmbH
Service VSF
Unternehmensbereich Elektronik
fuer Wissenschaft und Industrie
Oskar-Messter-Strasse 18
D-8045 Ismaning
TEL: 49 89 9605 261

Finland
Oy Phillips AB
Central Service
Sinikalliontie 1-3
P.O. Box 11
02631 ESPOO
TEL: 358 0 52572
TLX: 121875 fixheps

France
S.A. Phillips Industrielle
et Commerciale,
Science et Industry
105 Rue de Paris BP 62
93002 Bobigny, Cedex
TEL: 33-1-4942-8040
TLX: 210290 induphi

Greece
Phillips S.A. Hellenique
15,25th March Street
177 78 Tavros
10210 Athens
TEL: 30 1 4894911
TLX: 241566/241567frtgraa

Hong Kong
Schmidt & Co (H.K.) Ltd.
18/FL., Great Eagle Centre
23 Harbour Road
Wanchai
TEL: 852 5 8330222
TLX: (780) 76762 SCHMC HX

India
Hinditron Services Pvt. Inc.
33/44A Raj Mahal Vilas Extension
8th Main Road
Bangalore 560 080
TEL: 91 812 363139
TLX: (953) 845271 HSPL IN

Hinditron Services Pvt. Ltd
1st Floor, 17-B,
Mahal Industrial Estate
Mahakali Road, Andheri East
Bombay 400 093
TEL: 91 22 6300043
TLX: (953) 11-79387 HEMC IN

Hindtron Services Pvt. Ltd.
15 Community Centre
Panchshila Park
New Delhi 110 017
TEL: 011-6433675
TLX: (953) 031-61458 HCPL IN

Hinditron Services Pvt. Ltd.
Field Service Center
Emerald Complex 1-7-264
5th Floor
114 Sarojini Devi Road
Secunderabad 500 003
TEL: 08 42-821117
TLX: (953) 425-6973

Israel
R.D.T Electronics Engineering, Ltd.
P.O. Box 43137
Tel Aviv 61430
TEL: 972-3-483211
TLX: (922) 371452 RDT IL

Italy
Phillips S.P.A.
Sezione I&E / T&M
Viale Elvezia 2
20052 Monza
TEL: 39-39-363-5315
TLX: 333343 phils i

Japan
Fluke Corporation
Sumitomo Higashi Shinbashi Bldg.
1-1-11 Hamamatsucho
Minato-ku
Tokyo 105
TEL: 03 3434-0181
TLX: (781) 2424331 FLUKJPJ

Korea
Myoung Corporation
Yeo Eui Do P.O. Box 14
Seoul 150
TEL: 82 2 784-9942
TLX: K24283 MYOUNG

Malaysia
Mecomb Malaysia Sdn. Bhd.
P.O. Box 24
46700 Petaling Jaya
Selangor
TEL: 60 3 774-3422
TLX: (784) MA37764 MECOMB

Mexico
Mexel Mexicana De Electronica
Industrial, S.A. De C.V.
Calle Diagonal #27 3er.
Col. Del Valle
C.P. 03100, Mexico D.F.
TEL: 52-5-682-8040
TLX: 1171038 FAIRME

Netherlands
Phillips Nederland
Test & Measurement Division
Postbox 115
5000 AC Tilburg
TEL: 31-13-390172
TLX: 52683 FLUKE

New Zealand
Phillips Custial Support
Scientific & Industrial
2 Wagener Place
Mt. Albert
Auckland
TEL: 64 9 894-160
TLX: NZ 2395 ARGENTA

Norway
Norsk A/S Phillips
I&E Service
Sandstuveien 70
Postboks 1 Manglerud
N 0680 OSLO 6
TEL: 47-2-680200
TLX: 72640 phips n

Pakistan
Internation Operations (PAK) Ltd.
505 Muhammadi House
I.I. Chundrigar Road
P.O. Box 5323
Karachi
TEL: 92 21 221127, 239052
TLX: (952) 24494 PIO PK

Peru
Importaciones & Representaciones
Electronicas S.A.
Avad Franklin D. Roosevelt 105
Lima 1
TEL: 51 14 288650
TLX: (394) 25663 PE IREING

Philippines
Spark Electronics Corp.
P.O. Box 610, Greenhills
Metro Manila 1502
TEL: 63 2 700-621
TLX: (722) 27901 RLA PH

Portugal
Phillips Portuguese S.A.
I&E Division
Estrada de Outurela-Camaxide
2795 LINDA-A-VELHA
TEL: 418 00 71
TLX: 65120 PTLPGAJ

Republic of South Africa
South African Phillips (Pty) Ltd.
I&E Service Mgr.
P. O. BOX 7703
Johannesburrq 2000
TEL: 27 11 889-3224
TLX:

Singapore
Rank O'Connor's Singapore Pte Ltd
98 Pasir Panjang Road
Singapore 0511
TEL: 65 4737944
TLX: (786) RS21023 OCONSIN

Spain
Phillips Iberica Sae
Depto. Tecnico Instrumentacion
c/Martinez Villergas 2
28027 Madrid
TEL: 34 1 4042200
TLX: 052-27710 dsxma eesm/op

Sweden
Phillips Kistaindustrier AB
I&E Technical Customer Support
Borgarfjordsgatan 16
S 164 93 Kista
TEL: 46-8-703-1000
TLX: 854 17173 PHILKI S

Switzerland
Phillips A.G.
Technischer Kundendienst
Postfach 670
Allmendstrasse 140
CH-8027 Zurich
TEL: 41 1 488 29 63
TLX: 815 780 11

Taiwan, R.O.C.
Schmidt Electronics Corp.
5th Floor, Cathay Min Sheng
Commercial Building,
344 Min Sheng East Road
Taipei
TEL: 886 2 501-3468
TLX: (785) 11111 SCHMIDT

Thailand
Measuretronix Ltd.
2102/31 Ramkamhaeng Road
Bangkok 10240
TEL: 66 2 375-2733,375-2734
TLX: (788) 82796 HUAMARK TH

Turkey
Turk Phillips Ticaret A.S.
Inonu Caddesi 78/80
Posta Kutusu 504-Beyoglu
Istanbul
TEL: 90 1 1435891
TLX: 24192 phtr trtrxibph

Uruguay
Coasin Uruguay S.A.
Casilla de Correo 1400
Libertad 2525
Montevideo
TEL: 598-2-789015
TLX: (398) COAUR UY23010

Venezuela
Coasin C.A.
Calle 9 Con Calle 4, Edif. Edinurbi
Apartado de Correos Nr-70-136
Los Ruices
Caracas 1070-A
TEL: 58 2 241-0309, 241-1248
TLX: (395) 21027 EMVEN VC

List of Tables

TABLE	TITLE	PAGE
1-1.	Specifications	1-1
3-1.	Recommended Test Equipment	3-1
3-2.	Ohms Function Performance Test	3-8
3-3.	Fault Diagnosis Guide	3-11

List of Illustrations

FIGURE	TITLE	PAGE
2-1.	Overall Functional Block Diagram	2-2
2-2.	A/D Conversion Elements and Waveform	2-3
2-3.	Digital Circuitry Within U1	2-4
3-1.	Battery and Fuse Replacement	3-2
3-2.	Disassembly	3-4
3-3.	Switch Extension Shaft Installation	3-5
3-4.	Calibration Adjustment Locations	3-9

MANUFACTURERS SUPPLY CODES

01121 Allen-Bradley Co. Milwaukee, WI	15238 ITT Semiconductors A Div. of International Telephone & Telegraph Corp. Lawrence, MA	30035 Jolo Industries Inc. Garden Grove, CA	59717 Eveready Battery Co. Inc. St. Louis, MO	74594 Component Resources Inc. Div of EPI International Corp. Beaverton, OR
04222 AVX Corp. AVX Ceramics Div. Myrtle Beach, SC	17856 Siliconix Inc. Santa Clara, CA	37942 Mallory Capacitor Corp. Sub of Emhart Industries Inc. Indianapolis, IN	61429 Fox Electronics Fort Myers, FL	75915 Littelfuse Tracor, Inc. (Formerly: Tracor-Littelfuse) Des Plaines, IL
04713 Motorola Inc. Semiconductor Products Sector Phoenix, AZ	18520 Sharp Electronics Corp. Professional Products Div. Mahwah, NJ	39003 Maxim Industries Middleboro, MA	61857 SAN-O Industrial Corp. Bohemia, NY	79136 Waldes Kohinoor, Inc. Long Island, NY
05347 Ultronix Inc (Tel Labs) Grand Junction, CO	22526 DuPont, El DeNemours & Co. Inc. DuPont Electronic Dept. New Cumberland, PA	43744 Panasonic Industrial Co. San Antonio, TX	62351 Apple Rubber Products Inc. Lancaster, NY	76970 Connor Spring & Mfg. Co. San Jose, CA
09214 General Electric Co. Semiconductor Products Dept. Auburn, NY	22670 GM Nameplate, Inc. Seattle, WA	51406 Murata Erie, No. America Inc. Symrna, GA	68919 Inter-Technical Group Inc., The Wima Division Elmsford, NY	86928 Seastrom Mfg. Co. Inc. Glendale, CA
0K392 Shin-Etsu Silicones of America (S P America) Torrance, CA	25099 Cascade Gasket & Mfg. Co. Inc. Kent, WA	52769 Sprague-Goodman Electronics Inc. Garden City Park, NY	71400 Bussman Div. of Cooper Industries Inc. St. Louis, MO	89536 John Fluke Mfg. Co., Inc. Everett, WA
14936 General Instrument Corp. Power Semiconductor Div. Hicksville, NY	27014 National Semiconductor Corp. Santa Clara, CA	54583 TDK Electronics Corp. Port Washington, NY	71590 CRL Components Inc. Formerly Mepco/Centralab A North American Phillips Co. Fort Dodge, IA	91637 Dale Electronics Inc. Columbus, NE
	2K160 Parker Seal Co. Div of Parker-Hannifin Corp. Seattle, WA	56289 Sprague Electric Co. Nashua, NH	73734 Federal Screw Products Inc. Chicago, IL	91984 Maida Development Co. Hampton, VA
		59124 KOA-Speer Electronics Inc. Bradford, PA		

SERVICE CENTERS

USA	Texas	INTERNATIONAL	Belgium
California Fluke Service Center 46610 Landing Parkway Fremont, CA 94538 TEL: (510) 651-5112 FAX: (510) 651-4962	Fluke Service Center 2104 Hutton Drive Suite 112 Carrollton, TX 75006 TEL: (214) 406-1000 FAX: (214) 406-1072	Argentina Coasin S.A. Virrey del Pino 4071 DPTO E-65 1430 CAP FED Buenos Aires TEL: 54 1 522-5248 TLX: (390) 22284 COASN AR	Phillips Professional System S.A. I & E Division Service Department Rue des Deux Gares 80 1070 Brussels TEL: 32 2 525-6111 TLX: TX61511.PHEMBEL/BRMS
Fluke Service Center 16715 Von Karman Avenue Suite 110 Irvine, CA 92714 TEL: (714) 863-9031 FAX: (714) 757-7556	Washington Fluke Service Center Fluke Corporation Building #4 1420 - 75TH St. S.W. M/S 6-30 Everett WA 98203 TEL: (206) 356-5560 FAX: (206) 356-6390	Australia Phillips Customer Support Scientific and Industrial 23 Lakeside Drive Tally Ho Technology Park East Burwood Victoria 3151 TEL	Brazil Hi-Tek Electronica Ltda. Al. Amazonas 422, Alphaville CEP 06400 Barueri Sao Paulo TEL: 55 011 421-5477 TLX: (391) 11 71413 HITK BR
Florida Fluke Service Center 550 S. North Lake Blvd. Altamonte Springs, FL 32701-5227 TEL: (407) 331-2929 FAX: (407) 331-3366 or 331-7710		Phillips Customer Support Scientific and Industrial 25-27 Paul St. North North Ryde, N.S.W. 2113 TEL: 61 2 888-8222 TLX: (790) AA20165 AUSNRSI+PHILIND	Canada Fluke Electronics Canada Inc. 400 Britannia Road East, Unit #1 Mississauga, Ontario L4Z 1X9 TEL: 416 890-7600
Illinois Fluke Service Center 1150 W. Euclid Avenue Palatine, IL 60067 TEL: (708) 705-0500 FAX: (708) 705-9989		Austria Oesterreichische Phillips Industrie Unternehmensbereich Prof. Systeme Triesterstrasse 66 Postfach 217 A-1101 Wein TEL: 43 222-60101x1388 TLX: 133129	Chile Intronsa Inc.. Casilla 16158 Santiago 9 TEL: 56 2 232-1886, 232-4308 TLX: (332) 346351 INTRON CK
New Jersey Fluke Service Center W. 75 Century Rd or P.O. Box 930 Paramus, N.J. 07652 TEL: (201) 599-9500 (599-0919) FAX: (201) 599-2093			China Fluke Service Center Room 2111 Scite Tower Jianguomenwai Dajie Beijing 100004, PRC TEL: 86 1 512-3436 or 6351 TLX: (716) 222529 FLUKE CN


**REPLACEABLE PARTS
A2 DIGITAL PCB ASSEMBLY**

Table 4-3. A2 Digital PCB Assembly

REFERENCE DESIGNATOR	S	DESCRIPTION	FLUKE STOCK NO	MFRS SPLY CODE	MANUFACTURERS PART NUMBER OR GENERIC TYPE	TOT QTY	N 0 T E
C 12, 13, 44		CAP, CER, 0.22UF, +80-20%, 50V, Z5U	733386	04222	SR595E224ZAA	6	
C 47			733386				
J 8		SOCKET, 1 ROW, PWB, 0.100CTR, 18 POS	707026	30035	SS-109-1-18	1	
LS 1		AF TRANSD, PIEZO, 24 MM	602490	51406	PKM24-4A1	1	
U 2	*	IC, CMOS, 4 BIT MICROCOMPUTER	685628	18520	LU-04126P	1	

An * in 'S' column indicates a static-sensitive part.

**Section 1
Introduction and Specifications**



8025A-1602

Figure 4-3. A2 Digital PCB Assembly

NOTE

This meter has been designed and tested according to IEC Publication 348, Safety Requirements for Electronic Measuring Apparatus. This manual contains information and warnings which must be followed to ensure safe operation and retain the meter in safe condition.

1-1. INTRODUCTION

This manual presents service information for the Fluke 25 and 27 Multimeters. Included are a theory of operation, general maintenance procedures, performance tests, calibration procedures, troubleshooting information, a list of replaceable parts, and a schematic diagram.

1-2. OPERATING INSTRUCTIONS

For operating instructions, refer to the Operator's Manual provided with the instrument at time of purchase.

1-3. SPECIFICATIONS

Instrument specifications are presented in Table 1-1.

Table 1-1. Specifications

FUNCTION	RANGE	RESOLUTION	ACCURACY		
V	3.200V	0.001V	±(0.1%+1)		
	32.00V	0.01V	±(0.1%+1)		
	320.0V	0.1V	±(0.1%+1)		
	1000V	1V	±(0.1%+1)		
mV	320.0 mV	0.1 mV	±(0.1%+1)		
	320.0Ω	0.1Ω	±(0.3%+2)		
Ω (nS)	3.200 kΩ	0.001 kΩ	±(0.2%+1)		
	32.00 kΩ	0.01 kΩ	±(0.2%+1)		
	320.0 kΩ	0.1 kΩ	±(0.2%+1)		
	3.200 MΩ	0.001 MΩ	±(0.2%+1)		
	32.00 MΩ	0.01 MΩ	±(1%+1)		
	32.00 nS	0.01 nS	±(2%+10)		
(() →)	2.080V	0.001V	±(1%+1) typical		
	V	3.200V 32.00V 320.0V 1000V	40 Hz-2 kHz	0.001V	±(0.5%+3)
0.01V				±(0.5%+3)	±(4%+10)
2 kHz-10 kHz			0.1V	±(0.5%+3)	±(4%+10)
			1V	±(1%+3)	Not Specified
10 kHz-30 kHz			±(0.5%+3)	±(2%+3)	±(4%+10)
			±(2%+3)	±(3%+3)	±(4%+10)

FUNCTION	RANGE	RESOLUTION	ACCURACY	TYPICAL BURDEN VOLTAGE
mA/A	32.00 mA	0.01 mA	±(0.75%+2)	5.6 mV/mA
	320.0 mA	0.1 mA	±(0.75%+2)	5.6 mV/mA
	10.00A	0.01A	±(0.75%+2)	50 mV/A
μA	320.0 μA	0.1 μA	±(0.75%+2)	0.5 mV/μA
	3200 μA	1 μA	±(0.75%+2)	0.5 mV/μA
mA/A 40-1000 Hz	32.00 mA	0.01 mA	±(1.5%+2)	5.6 mV/mA
	320.0 mA	0.1 mA	±(1.5%+2)	5.6 mV/mA
	10.00A	0.01A	±(1.5%+2)	50 mV/A
μA 40-1000 Hz	320.0 μA	0.1 μA	±(1.5%+2)	0.5 mV/μA
	3200 μA	1 μA	±(1.5%+2)	0.5 mV/μA

FUNCTION	OVERLOAD PROTECTION	INPUT IMPEDANCE (nominal)	COMMON MODE REJECTION RATIO (1 kΩ unbalance)	NORMAL MODE REJECTION
V	1000V rms	10 MΩ in // with <100 pF	>120 dB at dc, 50 Hz, or 60 Hz	>60 dB at 50 Hz or 60 Hz
mV	500V rms	10 MΩ in // with <100 pF	>120 dB at dc, 50 Hz, or 60 Hz	>60 dB at 50 Hz or 60 Hz
V	1000V rms (10 ⁷ V-Hz max)	10 MΩ in // with <100 pF (ac coupled)	>60 dB, dc to 60 Hz	
mV	500V rms (10 ⁷ V-Hz max)	10 MΩ in // with <100 pF (ac coupled)	>60 dB, dc to 60 Hz	
Ω	500V rms	OPEN CIRCUIT TEST VOLTAGE <2.8V dc	FULL SCALE VOLTAGE	
			Up to 3.2 MΩ	32 MΩ or nS
			<420 mV dc	<1.3V dc

Basic electrical accuracy is specified from 18°C to 28°C with relative humidity up to 95%, for a period of one year after calibration. All ac conversions are ac coupled, average responding, and calibrated to read the true rms value of a sine wave input. Accuracy is specified as ±([% of reading] + [number of least significant digits]).

Ranging is either automatic or manual in all functions with more than one range. Test resistance below approximately 150Ω in the ((|||) →) function produces a continuous audible tone.




Figure 4-2. A1 Main PCB Assembly

8025A-1601

REPLACEABLE PARTS
A1 MAIN PCB ASSEMBLY

Table 4-2. A1 Main PCB Assembly (cont)

REFERENCE DESIGNATOR	DESCRIPTION	FLUKE STOCK	MFRS SPLY	MANUFACTURERS PART NUMBER	TOT QTY	N O T
-A>-NUMERICS--> S	--NO--	-CODE-	-OR	GENERIC TYPE----	QTY-	-E-
RJ 1- 5	VARISTOR, 430V, +-10%, 1MA	706838	09214	V264LAX1398	5	
RT 1, 2	THERMISTOR, RECT., POS., 1K, +-40%, 25C	446849	54583	911P84E102YU13	2	
S 1	SWITCH, ROTARY (UPPER)	654301	71590	654301	1	
S 2	SWITCH, ROTARY (LOWER)	654319	71590	654319	1	
U 1	8025 AP25 CHIP ASSEMBLY TESTED	700112	89536	700112	1	
U 7	DIODE, SI, RECT, BRIDGE, BV=50V, IO=1A	418582	14936	DF005M	1	
VR 1	* IC, 1.23V, 60PPM TC, BAND-GAP REFERENCE	654707	27014	LM285BXZ-1.2D26Z	1	
W 3	WIRE, MILLIAMP JUMPER	722967	89536	722967	1	
XF 1	CONTACT, 600V, FUSE	659524	7G970	659524	2	
XF 2	HLDR, FUSE, 5MM X 20MM	697086	61857	H-0011-2	2	
XF 3	600 VOLT FUSE CONTACT	707190	7G970	707190	2	
XBT 1	CONTACT ASSY TERMINATION	651653	89536	651653	1	
Y 1	CRYSTAL, 32.768KHZ, +-1%, 3 X 8MM	643031	61429	FOX-32.768	1	
Z 1	* OHMS/INPUT RES NET ASSY TESTED JP25	616938	89536	616938	1	

An * in 'S' column indicates a static-sensitive part.

1. Fusible resistor. To ensure safety, use exact replacement only.

Table 1-1. Specifications (cont)

MAXIMUM VOLTAGE BETWEEN ANY TERMINAL AND EARTH GROUND	FUNCTION	FUSE PROTECTION
1000V	mA or μ A A	630 mA 250V FAST, 3A 600V FAST 15A 600V FAST
Digital Display	3200 counts, updates 2/sec	
Analog Display	31 segments, updates 25/sec	
Operating Temperature	-15°C to 55°C, to -40°C for 20 minutes when taken from 20°C	
Storage Temperature	-55°C to 85°C	
Temperature Coefficient	0.1 x (specified accuracy)/°C (<18°C or >28°C)	
Relative Humidity	0% to 95% (0°C to 35°C) 0% to 70% (35°C to 55°C)	
Battery Type	9V, NEDA 1604 or 6F22 or 006P	
Battery Life	1000 hrs typical	
Shock, Vibration and Water Resistance	Per MIL-T-28800 for a Style A, Class 2 Instrument	
Size (HxWxL)	2.2 in x 3.75 in x 8 in (5.6 cm x 9.5 cm x 20.3 cm)	
Weight	1.6 pounds (0.75 kg)	
Safety	Protection Class II per IEC 348 and ANSI C39.5	

**REPLACEABLE PARTS
A1 MAIN PCB ASSEMBLY**

Table 4-2. A1 Main PCB Assembly

REFERENCE DESIGNATOR	FLUKE STOCK	MFRS SPLY	MANUFACTURERS PART NUMBER	TOT QTY	N O T	
-A>-NUMERIC-->	S-----	DESCRIPTION-----	--NO--	-CODE-	-OR GENERIC TYPE-----	QTY- E-
A 3		* FUSE PCA	830224	89536	830224	1
AR 1		* IC, OP AMP, LOW POWER	721928	39003	IC7611DCPA	1
C 3		CAP, POLYES, 0.022UF, +-10%, 1000V	448183	37942	160-223K1000AH	1
C 4, 10		CAP, VAR, 0.25-1.5PF, 1700V, TEFLON	721480	52769	ER-530-016	2
C 5		CAP, CER, 2.7PF, +-0.25PF, 50V, COG	773044	89536	773044	1
C 6		CAP, VAR, 2-7PF, 100V, CER	714600	51406	TZ03Z070YR174	1
C 7		CAP, CER, 430PF, +-5%, 50V, COG	732644	04222	SR595A431JAA	1
C 8		CAP, VAR, 6-50PF, 50V, CER	714618	51406	TZ03Z500YR174	1
C 9		CAP, CER, 5100PF, +-2%, 50V, COG	732651	04222	SR595A512GAA	1
C 11		CAP, POLYCA, 0.027UF, +-5%, 63V	733444	68919	MKC2273J63V	1
C 16		CAP, TA, 10UF, +-20%, 10V	714766	56289	199D106X0010BG2	1
C 17, 50		CAP, CER, 33PF, +-5%, 50V, COG	714543	04222	SR595A330JAA	2
C 18, 19		CAP, POLYCA, 0.027UF, +-10%, 63V	720979	68919	MKC2-272-K-63V	2
C 20		CAP, POLYES, 0.47UF, +-10%, 50V	697409	37942	185-2-474K50AAB	1
C 21		CAP, POLYPR, 0.033UF, +-10%, 63V	721050	68919	MKP20-333K63V	1
C 22, 36		CAP, POLYES, 0.01UF, +-10%, 50V	715037	37942	185-2-103K50A/A	2
C 23, 37		CAP, TA, 22UF, +-20%, 10V	658971	56289	199D226X0010CG2	2
C 30		CAP, CER, 4.0PF, +-0.25PF, 1500V, COJ	714535	91984	6010COH4R0C1.5LVT14	1
C 31- 33, 40		CAP, CER, 0.22UF, +-80-20%, 50V, Z5U	733386	04222	SR595E224ZAA	4
C 34		CAP, POLYES, 1000PF, +-20%, 630V	740126	37942	167-102M630AB	1
C 35		CAP, POLYCA, 1000PF, +-20%, 100V	721472	68919	FKC2101M100V	1
C 38, 39		CAP, POLYES, 0.1UF, +-10%, 50V	649913	37942	185-2-104K50AAA	2
C 41, 42		CAP, CER, 10PF, +-20%, 50V, COG	721589	04222	SR595A100MAA	2
C 43		CAP, CER, 220PF, +-20%, 50V, COG	740654	04222	SR595A221MAA	1
C 48		CAP, POLYCA, 0.033UF, +-5%, 63V	733451	68919	MKC2333J63V	1
C 49		CAP, CER, 0.022UF, +-80-20%, 500V, Z5U	740340	51406	RPE113-901E223Z9	1
C 51		CAP, CER, 0.01UF, +-10%, 100V, X7R	557587	04222	SR591C103KAA	1
CR 1- 5		DIODE, SI, 1K PIV, 1.0 AMP	453399	04713	IN4007	5
CR 6		* DIODE, SI, BV=35V, LOW LEAKAGE	723817	17856	J2723TR	1
CR 7		* DIODE, SI, BV= 75.0V, RADIAL INSERTED	659516	15238	1N4448	1
L 1		RF COIL ASSEMBLY	857792	89536	857792	1
MP 1		SHIELD, FENCE	722280	70970	722280	1
MP 8		SUPPORT, PCB	656108	89536	656108	1
P 1		CONNECTOR, 18 PIN	707646	22526	707646	1
Q 1, 2, 11		* TRANSISTOR, SI, NPN, SELECTED IEBO, TO-92	685404	27014	SX14073A, SX12398	3
Q 12		* TRANSISTOR, SI, N-JFET, TO-92, RAD T&R	721936	17856	J2660	1
Q 13		* TRANSISTOR, SI, N-JFET, TO-92	723734	17856	J27138TR	1
Q 15		* TRANSISTOR, SI, PNP, T092	698233	04713	2N3906	1
R 1		RES, CC, 220K, +-10%, 1W	714485	01121	GB2241	1
R 2		RES, MF, 1K, +-1%, 100PPM, FLMPRF, FUSIBLE	650085	91637	CMF-65 69 1K F T-1 B	1
R 3		RES, MF, 301K, +-1%, 0.125W, 100PPM	655274	59124	MF50D3013F	1
R 4		RES, MF, 332K, +-1%, 0.125W, 100PPM	655217	59124	MF50D3323F	1
R 5		RES, CC, 100K, +-5%, 2W	285056	01121	HB1045	1
R 6, 25, 33, 41		RES, CF, 100K, +-5%, 0.25W	658963	59124	CF1/4 104J	4
R 7		RES, VAR, CERM, 1K, +-20%, 0.3W	706655	43744	EVM31G	1
R 9		RES, MF, 402K, +-0.1%, 0.125W, 100PPM	714329	59124	MF50D4023B	1
R 10		RES, MF, 44.8K, +-0.1%, 0.125W, 100PPM	714311	59124	MF50D4482B	1
R 12		RES, MF, 14.3K, +-1%, 0.125W, 100PPM	721803	59124	MF50D1432F	1
R 13		RES, CF, 1.5M, +-5%, 0.25W	649962	59124	CF1/4 155J	1
R 14		RES, MF, 500, +-0.25%, 0.25W, 100PPM	697557	59124	MF55D5000C	1
R 15		RES, MF, 107K, +-1%, 0.125W, 50PPM	714295	59124	MF50C1073F	1
R 16, 28, 29		RES, CF, 1M, +-5%, 0.25W	649970	59124	CF1/4 105J	3
R 18		RES, MF, 412K, +-1%, 0.125W, 50PPM	714287	59124	MF50C4123F	1
R 19		RES, VAR, CERM, 100K, +-20%, 0.3W	658989	51406	RVG0707H100A10-104M	1
R 20		RES, WW, 4.995, +-0.25%, 4W	658948	91637	RS-2 4.995 C	1
R 23		RES, WW, .005, +-0.5%, .5W	655423	05347	Q375A	1
R 26		RES, MF, 499K, +-1%, 0.125W, 100PPM	714980	59124	MF50D4993F	1
R 27		RES, MF, 1.5M, +-1%, 0.125W, 100PPM	714998	59124	MF50D1504F	1
R 30		RES, MF, 20K, +-0.25%, 0.125W, 50PPM	715029	59124	MF50C2002C	1
R 31, 32		RES, MF, 22.6K, +-0.25%, 0.125W, 50PPM	715011	59124	MF50C2262C	2
R 35		RES, CF, 4.7K, +-5%, 0.25W	721571	59124	CF1/4 472J	1
R 36		RES, CF, 47K, +-5%, 0.25W	721787	59124	CF1/4 473J	1
R 37		RES, MF, 5.49K, +-1%, 0.125W, 100PPM	721795	59124	MF50D5491F	1
R 38		RES, CF, 1.5, +-5%, 0.25W	732800	59124	CF1/4 1R5J	1
R 39		RES, CF, 300K, +-5%, 0.25W	732818	59124	CF1/4 304J	1
R 40		RES, CF, 200K, +-5%, 0.25W	681841	59124	CF1/4 204J	1
R 42		RES, CC, 15M, +-5%, .125W	875112	01121	BB1565	1

An * in 'S' column indicates a static-sensitive part.




Figure 4-1. 25/27 Final Assembly

Section 2 Theory of Operation

2-1. INTRODUCTION

This section describes how the Fluke 25 and Fluke 27 work. First, a functional description presents an overview of operation. This is followed by a block diagram description, which describes the major circuit functions in more detail. All descriptions apply to both instruments unless specified otherwise. For reference, a detailed schematic diagram is included in Section 5.

2-2. FUNCTIONAL DESCRIPTION

A block diagram of the Fluke 25/27 circuitry is shown in Figure 2-1. As this figure shows, the instrument is composed of two major functional sections: the analog section and the digital section. Each section contains one major active component and one or more peripheral circuits. Most analog functions are performed by a custom analog IC (U1) and analog peripherals to U1. Digital functions are performed by a CMOS, 4-bit microcomputer, U2.

The custom analog IC contains the A/D converter, signal conditioning circuits, and the digital control circuitry required for communication with the microcomputer. Although the custom IC is primarily analog, digital circuits provide state machine control for the A/D converter, a read counter for A/D samples, decoding ROMs for analog switch drive, and bus control for communication with the microcomputer.

The microcomputer controls the A/D converter, initiates the range and function switching, formats data for display, and drives the display. The mode push buttons supply input to the microcomputer to initiate various modes. Output from the microcomputer is displayed on the liquid crystal display (LCD).

2-3. BLOCK DIAGRAM DESCRIPTION

Each of the blocks in the Figure 2-1 is discussed in the following paragraphs. In many cases, circuit sections are described in greater detail than is shown in the Figure 2-1; therefore, it may be helpful to refer to the schematic located near the back of this manual.

2-4. Input Overload Protection

Overload protection for the volts/ohms/diode-test input (J1) is provided by a network of five metal-oxide varistors (RJ1 through RJ5) and two current-limiting resistors (R1 and R2). R2 is a 1-k Ω , 2W fusible resistor that will open if an extremely high energy signal is present.

Two fuses in series provide protection for the mA/ μ A input (J2) current shunts: a 3A, 600V fuse and a 630 mA, 250V fuse. A single 15A, 600V fuse provides protection for the 10A input (J3) current shunt. In addition, for the μ A and mA ranges, a bridge rectifier (U7) and four diodes (CR1, CR2, CR3, CR4) ensure that the fuses (instead of the shunts) open in very high current overload conditions.

Transistors Q1, Q2, and Q11 provide additional overload protection for the millivolt and ohms functions. If sufficient overload voltage is present, the transistors turn on and connect that input to common through limiting resistor R2, thereby protecting the circuitry in U1. A clamp circuit (CR6 and Q15) connected to the volt/ohms/diode-test input through Z1 and C3 provides similar protection for the volts/ohms/diode-test input.

2-5. Function Switching Circuits

Input signals are routed from the overload protection circuits to the function switch. The function switch is a rotary switch with two double-sided wafers which provide

the necessary switching to select each of the various functions. In addition, battery voltage is routed through the function switch from the battery voltage regulator to U1, and from U1 to U2.

2-6. Signal Conditioning Circuits

Each input signal is routed through signal conditioning circuitry before reaching U1. Input signals received through the volts/ohms/diode-test input (J1) are routed through Z1, a precision resistor network. The resistor network provides precise input scaling for the various voltage ranges, and it provides precision reference resistors for the ohms function. The capacitors in parallel with the various resistors in Z1 are used in the ac voltage functions; the variable capacitors provide calibration adjustment for the high frequency ac ranges.

Current inputs received through the mA/ μ A input (J2) and the A input (J3) develop a voltage across shunt resistors R14, R20, and R23 (320 μ A, 32 mA, and 10A respectively). Resistors R9 and R10 comprise a 10:1 divider for the 3200- μ A and 320-mA current ranges.

2-7. Custom Analog IC (U1)

The analog-to-digital converter, autorange switching, and most of the remaining active analog circuitry

(including additional signal conditioning) are contained in U1, a custom LSI package. Peripherals to U1 include the system clock, the reference voltage regulator for the A/D converter, and some filtering and amplifier stabilization components. U1 also contains digital circuitry for state machine control over the A/D converter phases, a read counter for A/D samples, decoding ROMs for analog switch drive and read counter preset, and registers to store control outputs from the microcomputer.

Analog-to-digital conversion is accomplished within U1 using a modified dual-slope A/D converter circuit, as shown in Figure 2-2. The conversion method in the Fluke 25/27 can be described as a charge-coupled, multiple-slope technique. A series of 10 minor conversions occur every 40 ms (each at 1/10th the desired resolution) without taking time for an autozero phase between the conversions. These minor conversions (or samples, as they are called in the following discussion) occur at a rate of 25 per second, and are used to provide the fast response bar-graph display and fast autoranging.

New samples are taken every 40 ms. Ten samples are summed to produce a full-resolution digital display, with full scale greater than 3200 counts. A 100-ms autozero phase occurs following every 10-sample sequence.




Figure 2-1. Overall Functional Block Diagram

Table 4-1. 25/27 Final Assembly

REFERENCE DESIGNATOR	FLUKE STOCK NO	MFRS SPLY CODE	MANUFACTURERS PART NUMBER OR GENERIC TYPE	TOT QTY	N O T -E-	
A 1	855726	89536	855726	1		
A 2	654137	89536	654137	1		
BT 1	696534	59717	216	1		
F 1	756601	71400	BBS-3-600V	1		
F 2	845040	75915	216-630MA	2		
F 3	820829	71400	KTK-15	1		
H 1	696591	86928	30-19587	1		
H 2	682310	89536	682310	2		
H 3	721670	89536	721670	4		
H 4	448456	89536	448456	3		
H 5	129890	89536	129890	4		
H 6	682070	89536	682070	4		
H 7	733394	89536	733394	4		
H 8	157008	74594	157008	2		
H 9	739912		COMMERCIAL	2		
MP 1			CASE TOP	1	1	
			FLUKE 25 STD	657486	89536	657486
			FLUKE 25 YEL	744490	89536	744490
			FLUKE 27 STD	659946	89536	659946
			FLUKE 27 YEL	744508	89536	744508
MP 2			KNOB SWITCH			1
			STD	654012	89536	654012
			YEL	744466	89536	744466
MP 3			BOTTOM SHIELD ASSEMBLY	654079	89536	654079
MP 4			O-RING, SYN RUBBER, .114 ID, .070 WIDE	705947	2K160	2-006N163-70
MP 5			SPRING, DETENT	654046	89536	654046
MP 6			RING, RET, EXT, FLAT, STL, .188 DIA	697078	79136	X5133-18-ZD
MP 7			DECAL, TOP CASE			1
			FLUKE 25 STD	654475	89536	654475
			FLUKE 25 YEL	744557	89536	744557
			FLUKE 27 STD	659466	89536	659466
			FLUKE 27 YEL	744565	89536	744565
MP 8			SUPPORT, TOP SHIELD	654038	89536	654038
MP 9			SHIELD, TOP	654384	22670	654384
MP 10			CASE BOTTOM			1
			STD	830133	89536	830133
			YEL	830141	89536	830141
MP 11			FOOT, CASE	654335	25099	654335
MP 12			BAIL, TILT			1
			STD	654053	89536	654053
			YEL	744474	89536	744474
MP 13			O-RING, SYN RUBBER, 6.710, .080	654392	62351	6.710X.080-40BN
MP 14			COVER, BATTERY			1
			STD	830158	89536	830158
			YEL	830166	89536	830166
MP 15			O-RING, SYN RUBBER, 1.612 ID, .103 WIDE	697185	2K160	2-130N545-40
MP 16			RETAINER, BATTERY			1
			STD	660985	89536	660985
			YEL	744615	89536	744615
MP 17			SHAFT, SWITCH	655894	89536	655894
MP 18			SUPPORT, LCD INTERCONNECT	683664	89536	683664
MP 19			MASK, LCD			1
			FLUKE 25	654020	89536	654020
			FLUKE 27	661025	89536	661025
MP 20			CONN, ELASTOMERIC, LCD TO PWB, 1.970 L	682500	0K392	SG
MP 21			DECAL, MSHA APPROVAL, FLUKE 25/27			1
			STD	809863	89536	809863
			YEL	809871	89536	809871
MP 23			TEST LEADS	855742	89536	855742
MP 24			DECAL, WARNING			1
			STD	685719	89536	685719
			YEL	744607	89536	744607
MP 25			ALLIGATOR CLIP BLACK	738047	89536	738047
MP 26			ALLIGATOR CLIP RED	738120	89536	738120
S 3			SWITCH, MOMENTARY			1
			FLUKE 25	654343	89536	654343
			FLUKE 27	659847	89536	659847
TM 1			25 27 MANUAL	738088	89536	738088
U 3			LCD, 3.75 DIGIT, BAR GRAPH, MULTIPLEXED	654293	18520	LF-7036G

An * in 'S' column indicates a static-sensitive part.

NOTES:

1. FLUKE 25/27 MULTIMETER STANDARD (STD) OR YELLOW (YEL).
2. 25/27 RECOMMENDED SPARE PARTS KIT, FLUKE STOCK NUMBER 744946. (CUSTOMER OPTION)

**REPLACEABLE PARTS
MANUAL STATUS INFORMATION**

To ensure prompt delivery of the correct part, include the following information when you place an order:

- Instrument model and serial number
- Part number and revision level of the pca containing the part.
- Reference designator
- Fluke stock number
- Description (as given under the DESCRIPTION heading)
- Quantity

4-3. MANUAL STATUS INFORMATION

The Manual Status Information table that precedes the parts list defines the assembly revision levels that are documented in the manual. Revision levels are printed on the component side of each pca.

4-4. NEWER INSTRUMENTS

Changes and improvements made to the instrument are identified by incrementing the revision letter marked on the affected pca. These changes are documented on a supplemental change/errata sheet which, when applicable, is included with the manual.

4-5. SERVICE CENTERS

A list of service centers is located at the end of this section.

NOTE

The Fluke 25 and 27 Multimeters have been designed to meet the requirements of the United States Department of Labor Mine Safety and Health Administration for use in mines. If your instrument has MSHA approval, a decal stating so will be present on the bottom of your instrument. The following WARNING applies only if the decal is present:

WARNING

THE FLUKE 25 AND 27 MULTIMETERS ARE APPROVED (PERMISSIBLE) BY THE

UNITES STATES DEPARTMENT OF LABOR MINE SAFETY AND HEALTH ADMINISTRATION (MSHA) FOR USE IN MINES (APPROVAL 2G-3665-0). TO MAINTAIN MSHA PERMISSIBILITY, REPAIRS TO THESE INSTRUMENTS MUST BE MADE USING PARTS EXACTLY LIKE THOSE FURNISHED BY THE FLUKE CORPORATION. ANY CHANGES IN THE INTRINSICALLY SAFE CIRCUITRY OR COMPONENTS MAY RESULT IN AN UNSAFE CONDITION. THE FLUKE 25 AND 27 MULTIMETERS WERE TESTED BY THE MSHA FOR INTRINSIC SAFETY IN METHANE AIR MIXTURES ONLY. THE FLUKE 25 AND 27 MULTIMETERS ARE MSHA APPROVED WITH A 9V NEDA 1604 (CARBON ZINC) BATTERY ONLY. DO NOT USE TO CHECK ELECTRICAL BLASTING CIRCUITS. DO NOT CONNECT TO AN ELECTRICALLY ENERGIZED CIRCUIT IN A HAZARDOUS AREA.

WARNING

WHEN SERVICING, USE ONLY SPECIFIED PARTS.

WARNING

THIS INSTRUMENT CONTAINS A FUSIBLE RESISTOR (PN 650085). TO ENSURE SAFETY, USE EXACT REPLACEMENT ONLY.

Manual Status Information

REF OR OPTION NO.	ASSEMBLY NAME	FLUKE PART NO.	REVISION LEVEL
A1	Main PCB	855726	A
A2	Digital PCB	654137	E

**THEORY OF OPERATION
CUSTOM ANALOG IC (U1)**

Basic A/D conversion elements and waveforms are illustrated in Figure 2-2. As this figure shows, a residual charge is retained by the integrator capacitor due to the overshoot past the true-zero base line. In the absence of an autozero phase, the residual charge would normally produce a significant error in the sample next taken. However, a digital algorithm eliminates the error and accounts for the residue as it propagates through all 10 samples.

Digital circuitry in U1 provides state machine control for the A/D converter, a read counter for A/D samples, decoding ROMs for analog switch drive and for read counter preset, and bi-directional bus control for storing

control outputs from the microcomputer and for transferring data to the microcomputer. The digital circuitry within U1 is illustrated in Figure 2-3.

Basic timing for the A/D converter is defined as a series of 10 integrate/read cycles (samples), followed by a 100-ms autozero phase. However, the diode test and continuity function, the 32-MΩ range, the battery test, the power-up self test, overload recovery, autoranging, and the Touch-Hold mode all require variations from the basic timing. The state machine, in combination with the ROM and preset read counter, plus an autozero flag under computer control, establishes the timing variances necessary for the various functions.




Figure 2-2. A/D Conversion Elements and Waveform

THEORY OF OPERATION
PERIPHERALS TO U1




Figure 2-3. Digital Circuitry Within U1

Section 4
List of Replaceable Parts

TABLE OF CONTENTS

ASSEMBLY NAME	TABLE NO.	PAGE NO.	FIGURE NO.	PAGE NO.
25/27 Final Assembly	4-1	4-3	4-1	4-4
A1 Main PCB Assembly	4-2	4-5	4-2	4-7
A2 Digital PCB Assembly	4-3	4-8	4-3	4-8

2-8. Peripherals to U1

Circuitry peripheral to U1 provides regulated battery voltage to power U1, a regulated reference voltage for the A/D converter, a system clock, signal conditioning, and amplifier stabilization. The battery voltage regulator consists of AR1, Q12, and associated components; the regulator circuit supplies consistent operating power to U1 and, through a second regulator circuit in U1, to the microcomputer (U2). Voltage regulator VR1 (and associated components) supplies a regulated 1.000V reference voltage for the A/D converter. Potentiometer R19 provides for calibration adjustment of the reference voltage.

Additional circuits are necessary for the active filter, integrator, and buffer in U1. The active filter response is determined by R13, R16, C18, and C19. Integrator and buffer signal characteristics are determined by C20, C21, and two resistors in Z1. Several components external to U1 provide for ac-to-dc conversion; they are C41, C42, C43, R35, R7, C16, R30, R31, and R32.

The system clock, with a frequency of 32.768 kHz, controls all timing synchronization for the instrument. Y1 is a quartz crystal which determines the frequency of the clock oscillator circuit.

2-9. Microcomputer Control

A CMOS, 4-bit microcomputer (U2) controls the various instrument functions and drives the LCD display. The microcomputer reads and processes data samples from the A/D converter, sends a code to U1 which represents the operator-selected function, performs the Touch-Hold algorithm, selects the correct A/D mode for the function in use, controls range, sets the autozero flag, and disables the analog filter during autoranging.

In reading and processing A/D samples, the computer accepts raw sample data, applies necessary corrections as described in the preceding discussion of U1, and accumulates 10 samples which then become the full-resolution conversion for digital display. Each minor conversion is also processed for the bar-graph display. For the diode test and continuity function, the microcomputer evaluates the data and determines whether or not the beeper should be switched on.

Touch-Hold operation requires the microcomputer to perform a different algorithm. The microcomputer does not allow a full-resolution conversion to be completed unless the input signal is stable. When a stable reading occurs, the conversion is completed and the microcomputer generates the corresponding display and

4-1. INTRODUCTION

This section contains an illustrated list of replaceable parts for the Fluke 25 and 27 Multimeters. Parts are listed by assembly; alphabetized by reference designator. Each assembly is accompanied by an illustration showing the location of each part and its reference designator. The parts lists give the following information:

- Reference designator
- An indication if the part is subject to damage by static discharge
- Description
- Fluke stock number
- Manufacturers supply code (code-to-name list at the end of this section)
- Manufacturers part number or generic type
- Total quantity
- Any special notes (i.e., factory-selected part)

CAUTION

A * symbol indicates a device that may be damaged by static discharge.

4-2. HOW TO OBTAIN PARTS

Electrical components may be ordered directly from the manufacturer by using the manufacturers part number, or from the Fluke Corporation and its authorized representatives by using the part number under the heading FLUKE STOCK NO. In the U.S., order directly from the Fluke Parts Dept. by calling 1-800-526-4731. Parts price information is available from the Fluke Corporation or its representatives. Prices are also available in a Fluke Replacement Parts Catalog which is available on request.

In the event that the part ordered has been replaced by a new or improved part, the replacement will be accompanied by an explanatory note and installation instructions, if necessary.

4. Check pin 3 of Z1 for approximately 200 mV dc. If 200 mV is not present, either Z1 or U1 may be defective. (Measurement may be approximately 10% low if a 10-M Ω input impedance DVM is being used for signal tracing.)
5. Check the active filter input (pin 28 of U1) for approximately 200 mV dc. If 200 mV is not present, U1 may be defective. (Measurement may be affected by loading.)

6. Check the active filter output (pin 29 of U1) for approximately 200 mV dc. If 200 mV is not present, R13, R16, C18, or C19 may be defective. (Measurement may be affected by loading.)

3-26. Fault Diagnosis Guide

Table 3-3 presents a fault diagnosis guide for the Fluke 25 and 27. The left column lists various malfunction symptoms. The center column recommends actions to determine the exact problem. The right column lists the components most likely to be defective.

freezes it. The microcomputer then waits for a change in the signal to exceed a certain threshold, and then begins watching for a stable reading again. There are two exceptions to this simple algorithm: First, open test lead indication does not allow a full-resolution conversion to be completed either; the microcomputer continues to wait for a stable signal which is outside the open test lead region. (Open test leads in voltage or current functions result in low readings; open test leads in resistance or diode test functions result in off-scale readings.) Second, if the Touch-Hold button is momentarily pressed at any time, then the full-resolution conversion is forced to complete in spite of input or test lead conditions.

The microcomputer also sets the required A/D converter mode. A single mode is used in all voltage and current conversions, but there are three ohms function A/D converter modes, a diode test mode, and two power-up test modes (battery test and self test). The microcomputer sends the proper code to U1 to select the required A/D converter mode. Following each group of 10 samples, in normal operation, the microcomputer sets the autozero flag.

Both manual and autoranging are controlled by the microcomputer. The microcomputer loads a range register in U1 in conjunction with a mode-dependent map. In autorange, the analog filter is disabled to increase the autoranging speed.

Peripheral components Q13 and C12 force the microcomputer to reset when the function switch is moved to OFF. A voltage-divider network (R3, R4, and C13) supplies a mid-level voltage to drive the multiplexed display.

2-10. Display

The liquid-crystal display (LCD) operates under direct control of the microcomputer. Characters are generated by the computer and displayed on the LCD. Both digital readings and an analog bar-graph display are presented, in conjunction with annunciators and decimal points. Refer to the Fluke 25/27 Operator's Manual for a more detailed description of the display.

- d. Perform step 15 of the reassembly procedure to secure the main pcb to the input terminals.
2. Select the dc voltage function (\overline{V}).
3. Use a Digital Voltmeter (DVM) to check the battery voltage at the battery connector (battery voltage must be above 6.3V). If battery voltage is less than 7.5V, battery replacement is advised. Normal current drain is less than 600 μ A.
4. Connect either an oscilloscope or frequency counter, using a low-capacitance probe, to pin 54 of U1 or to the junction of C17 and Y1 (the crystal). A 32.768-kHz sine wave with an amplitude of approximately 600 mV peak-to-peak should be present at the junction of C17 and Y1 (3V peak-to-peak at U1, pin 54). Note that U2 and the display will not operate if the clock signal is not present. If the clock signal is not present, the most likely causes are U1, Y1, or C17.
5. Use a DVM to check for a reference voltage of 1.00V dc (adjustable through R19) at pin 13 of U1 or at the junction of R15 and R18. If the reference voltage is not present, the most likely causes are VR1, R12, R15, R18, R19, R37, or U1.
6. Use a DVM to check for Vm (voltage middle) at pin 55 of U2, pin 16 of J8, or at the junction of R3 and R4. Vm should be 1.6V dc \pm 0.1V. If Vm is not present, the most likely causes are R3, R4, or C13.

3-25. DC Voltage Signal Tracing

The following procedure is a step-by-step method of tracing a dc voltage input through the instrument's circuits to the output of the active filter. Faulty components in the input signal path can be identified using this procedure. All measurements are taken with respect to common.

1. Select the dc voltage function (\overline{V}), then apply a 2V dc input through the volts/ohms/diode-test input terminal.
2. Using a DVM, measure the 2V input at the input terminal (J1).
3. Check pin 1 of the input divider (Z1) for 2V dc. If 2V dc is not present, R2, S1, RJ1, RJ2, RJ3, RJ4, or RJ5 may be defective.

Table 3-3. Fault Diagnosis Guide

SYMPTOM	RECOMMENDED ACTION	POSSIBLE COMPONENT
Blank display	Do system check given in paragraph 3-24.	BT1, U1, U2, Y1, C13
Display reads zero in volt dc	Do dc signal tracing in paragraph 3-25.	R2, Z1, U1, S1
Display hangs up in self-test mode	Do system check given in paragraph 3-24.	R15, R18, R19, R12, R37, VR1, Z1, U1, C20, C21
Display reads OL or 0 in 320 mA range		R9, R10, U1
Display reads 0 in 320 mA or 10A ranges		F1, F2, F3, R9, R20, R14
AC volts is inaccurate	Check calibration	R31, R32, R29, R30
320 mV range reads OL		Q11, U1
AC volts measurement noisy at 50-60 Hz		R13, R16, C18, C19
Wrong annunciator displayed		S1R, U1
Volts inaccurate	Check calibration	RJ2-RJ5
Ohms inaccurate		Z1, U1
Intermittent display	Clean connectors and connector strips on LCD and pcb.	Display Assembly
Display reads constant offset in volts		C18, C19, C20 shorted
Ohms reads low or will not read OL		Q1, Q2 shorted or leaky
Ohms reads random or alternates between on scale and OL		R2, RT2

3-21. AC Voltage Calibration

There is a single ac-to-dc converter adjustment for basic ac voltage accuracy. However, each ac voltage range must be calibrated independently for high frequency accuracy. Variable capacitors provide these high frequency adjustments. There should be no interaction between the various ranges when adjustments are made in the specified order. Use the following procedure to calibrate the ac voltage ranges.

WARNING

THE FOLLOWING PROCEDURE REQUIRES THAT HIGH VOLTAGES BE SUPPLIED TO THE UUT FOR CALIBRATION. READ THE SAFETY PRECAUTIONS IN THE FLUKE 25/27 OPERATOR'S MANUAL BEFORE PERFORMING THE FOLLOWING PROCEDURE.

1. Select the ac voltage function (\tilde{V}) on the UUT.
2. Connect the DMM Calibrator to the volts/ohms/diode-test input terminal on the UUT.
3. Program the DMM Calibrator output for 2.7V ac at 100 Hz.
4. Adjust R7 to obtain a display of 2.700V ac $\pm 0.001V$ ac.
5. Program the DMM Calibrator output for 270V ac at 10 kHz.
6. Adjust C4 to obtain a display of 270.0V ac $\pm 0.1V$ ac.
7. Program the DMM Calibrator output for 1000V ac at 10 kHz.
8. Adjust C10 to obtain a display of 1000V ac $\pm 1V$ ac.
9. Program the DMM Calibrator output for 27.00V ac at 10 kHz.
10. Adjust C8 to obtain a display of 27.00V ac $\pm 0.01V$ ac.
11. Program the DMM Calibrator output for 2.700V ac at 10 kHz.
12. Adjust C6 to obtain a display of 2.700V ac $\pm 0.001V$ ac.
13. Program the DMM Calibrator output for 2.700V ac at 100 Hz.

14. Verify that the UUT display indicates 2.700V ac $\pm 0.017V$ ac.
15. Switch off both the DMM Calibrator and the UUT. Disconnect the DMM Calibrator from the UUT.
16. Refer to the instructions in paragraph 3-10 to reassemble the UUT after calibration.

3-22. TROUBLESHOOTING

CAUTION

Static discharge can damage CMOS components U1 and U2. Follow the handling precautions for static sensitive components given previously. Never remove or install components without first disconnecting all inputs to the instrument and turning the function selector switch to OFF.

Refer to Figure 3-3 and to the schematics in Section 5 of this manual as necessary during the following troubleshooting procedures.

3-23. Power-Up Self Test

When the function switch is moved to any position from the OFF position, the instrument performs a power-up self test. All LCD segments are switched on while the test is being performed (about 1 second), then the unit commences normal operation.


3-24. Overall System Check

If the LCD display segments do not light, or if other malfunction indications occur during power-up or operation, perform the following overall system check. All measurements are taken with respect to common. The overall system check is helpful in isolating a malfunction to the component area, and Table 3-3 provides further fault isolation within the component area. Refer to the disassembly and reassembly procedures as necessary (paragraphs 3-9 and 3-10).

1. Set up the instrument as follows:
 - a. Perform steps 1 through 10 of the disassembly procedure to remove the battery cover, bottom case, and main pcb/shield assembly from the instrument. (Skip step 5.)
 - b. Perform steps 21 through 23 of the disassembly procedure to remove the top and bottom shields from the main pcb.
 - c. Perform step 14 of the reassembly procedure to install the main pcb in the top case.

static awareness


A Message From
Fluke Corporation




Some semiconductors and custom IC's can be damaged by electrostatic discharge during handling. This notice explains how you can minimize the chances of destroying such devices by:

1. Knowing that there is a problem.
2. Learning the guidelines for handling them.
3. Using the procedures, packaging, and bench techniques that are recommended.


The following practices should be followed to minimize damage to S.S. (static sensitive) devices.




1. MINIMIZE HANDLING




3. DISCHARGE PERSONAL STATIC BEFORE HANDLING DEVICES. USE A HIGH RESISTANCE GROUNDING WRIST STRAP.




2. KEEP PARTS IN ORIGINAL CONTAINERS UNTIL READY FOR USE.




4. HANDLE S.S. DEVICES BY THE BODY.




5. USE STATIC SHIELDING CONTAINERS FOR HANDLING AND TRANSPORT.




8. WHEN REMOVING PLUG-IN ASSEMBLIES HANDLE ONLY BY NON-CONDUCTIVE EDGES AND NEVER TOUCH OPEN EDGE CONNECTOR EXCEPT AT STATIC-FREE WORK STATION. PLACING SHORTING STRIPS ON EDGE CONNECTOR HELPS PROTECT INSTALLED S.S. DEVICES.



6. DO NOT SLIDE S.S. DEVICES OVER ANY SURFACE.



9. HANDLE S.S. DEVICES ONLY AT A STATIC-FREE WORK STATION.



10. ONLY ANTI-STATIC TYPE SOLDER-SUCKERS SHOULD BE USED.

11. ONLY GROUNDED-TIP SOLDERING IRONS SHOULD BE USED.

7. AVOID PLASTIC, VINYL AND STYROFOAM® IN WORK AREA.

PORTIONS REPRINTED WITH PERMISSION FROM TEKTRONIX INC. AND GENERAL DYNAMICS, POMONA DIV.

3. Connect the DMM Calibrator to the UUT volt/ohms/diode-test input terminal and common, and switch on Calibrator power.
4. Program the DMM Calibrator output for 0.090V, then push the 50Ω divider override button on the Calibrator to place the Calibrator in the 2V range.
5. Verify that the UUT indicates approximately 0.090V and the beeper is sounding a continuous tone.
6. Increase the DMM Calibrator output to 0.11V. The beeper should turn off.
7. Increase the Calibrator output to 1.0V, then slowly decrease the Calibrator output to 0.6V. Note that the UUT beeper produces a short beep as the voltage descends through 0.7V (typical silicon diode threshold).

3-19. Calibration Preparation

Allow the UUT to stabilize at an ambient temperature of 21 to 25 degrees Celsius (70 to 77 degrees Fahrenheit) and at a relative humidity of less than 80% with the power off for at least 30 minutes before beginning calibration. Calibration adjustments require removal of the bottom cover. Complete steps 1 through 7 of the disassembly procedure given earlier in this section, and then reconnect the battery to the UUT's battery connector.

3-20. DC Voltage Calibration

The dc voltage function must be calibrated before calibrating the other functions. Use the following procedure to calibrate the dc voltage function.

1. Connect the DMM Calibrator to the UUT volts/ohms/diode-test input terminal and common. Refer to Figure 3-4 for calibration component locations.
2. Select the dc voltage function (V) on the UUT.
3. Switch on power to the DMM Calibrator, and program the Calibrator output for 2.700V dc.
4. Adjust potentiometer R19 on the UUT for a display indication of 2.700V on the 3V range.
5. Program the DMM Calibrator for zero output, and disconnect the Calibrator from the UUT.

3-18. CALIBRATION ADJUSTMENT

Under normal operating conditions, the Fluke 25 and 27 should maintain its specifications for a period of one year after calibration. If the instrument has been repaired, or if it has failed any of the performance tests, the following calibration adjustment procedures must be performed. Use a non-conductive tool for adjustments.

NOTE

In the following procedures, the Fluke 25 and 27 are referred to as the unit under test, or UUT.




Figure 3-4. Calibration Adjustment Locations

3. Switch on power to the DMM Calibrator and program the DMM Calibrator output for 27 mA at 50 Hz.
4. Verify that the UUT indicates between 26.58 and 27.42 mA.
5. Program the DMM Calibrator output for 200 mA at 50 Hz.
6. Verify that the UUT indicates between 196.8 and 203.2 mA.
7. Program the DMM Calibrator output for zero amps.
8. Switch the UUT to the ac $\mu\tilde{A}$ function ($\mu\tilde{A}$), then program the DMM Calibrator output for 2000 $\mu\tilde{A}$ at 500 Hz.
9. Verify that the UUT indicates between 1968 and 2032 $\mu\tilde{A}$.
10. Program the DMM Calibrator output for zero amps.
11. Disconnect the DMM Calibrator from the UUT, connect the DMM Calibrator to the Transconductance Amplifier, then connect the Transconductance Amplifier to the UUT amp (A) and common (COM) input terminals.
12. Switch the UUT to the AC mA/A function, then program the DMM Calibrator output for an output from the Transconductance Amplifier of 5A at 1 kHz.
13. Verify that the UUT indicates between 4.91 and 5.09A. Program the DMM Calibrator to standby.
14. Set the UUT to the dc $\overline{mA/A}$ function ($\overline{mA/A}$).
15. Program the DMM Calibrator output for an output from the Transconductance Amplifier of 5.0A dc.
16. Verify that the UUT indicates between 4.94 and 5.06A.
17. Program the DMM Calibrator to standby.
18. Disconnect the DMM Calibrator from the Transconductance Amplifier.
19. Turn the function switch on the UUT to the dc $\overline{mA/A}$ position ($\overline{mA/A}$).

20. Connect the DMM Calibrator output to the UUT mA/ μ A input terminal, then program the DMM Calibrator for an output of 27 mA dc.
21. Verify that the UUT indicates between 26.78 and 27.22 mA.
22. Program the DMM Calibrator output for 2700 $\overline{\mu A}$ dc. Set the UUT to the dc $\overline{\mu A}$ function ($\overline{\mu A}$).
23. Program the DMM Calibrator for 2.7 mA.
24. Verify that the UUT indicates between 2678 and 2722 μ A.

3-16. Ohms Function Performance Verification

The following test may be used to verify correct ohms function operation and to verify UUT accuracy in the various ohms ranges.

1. Connect the DMM Calibrator to the UUT using the volts/ohms/diode-test input terminal and common.
2. Turn the function switch to the Ω position.
3. Switch on power to the DMM Calibrator. Program the DMM Calibrator to the resistance values indicated in Table 3-2, and verify that the UUT indication is within the tolerances given for each input value.

Table 3-2. Ohm Function Performance Test

STEP	INPUT RESISTANCE	DISPLAY INDICATION
1	100 ohms	99.5 to 100.5
2	1000 ohms	.997 to 1.003k
3	10,000 ohms	9.97 to 10.03k
4	100,000 ohms	99.7 to 100.3k
5	1 megohm	.997 to 1.003M
6	10 megohm	9.89 to 10.11M
*7	open circuit	00.00 to 00.10 nS
*NOTE: Conductance (nS) range must be entered using manual range selection.		

3-17. Diode Test Performance Verification

The following procedure may be used to verify proper operation of the diode test function. (This test can not be performed unless the source can sink 0.6 mA at 0.9V.)

1. Turn the UUT function selection switch to the diode test function.
2. The UUT should display OL.

Section 3
Maintenance

WARNING

THESE SERVICE INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID ELECTRIC SHOCK, DO NOT PERFORM ANY SERVICING OTHER THAN OPERATOR MAINTENANCE UNLESS YOU ARE QUALIFIED TO DO SO.

3-1. INTRODUCTION

This section presents instructions for disassembly, performance tests, calibration adjustment, and troubleshooting. The performance tests may be used as an acceptance test when the instrument is first received, and can be used later as a preventive maintenance tool.

A 1-year calibration cycle is recommended to maintain the instrument's specifications. In addition, the seals should be replaced during servicing to maintain the environmental specifications stated in that manual. A seal kit is available from the factory. The seal kit (Model 8025A-7401, part number 738112) contains a complete set of seals and four replacement screws and washers for the bottom case.

The test equipment required for the performance tests and calibration adjustments is listed in Table 3-1. Test equipment with equivalent specifications may be used if the recommended models are unavailable.

3-2. SERVICE INFORMATION

The Fluke 25 and 27 are warranted for a period of two years upon shipment of the instrument to the original purchaser. Conditions of the warranty are described on the registration card. Malfunctions that occur within the limits of the warranty will be corrected at no cost to the purchaser. For in-warranty service, ship the instrument post-paid to the Fluke Service Center nearest you. A list of service centers is included at the back of this manual.

Fluke Service Centers are also available for calibration or repair of instruments that are beyond the warranty period. Upon request, a cost estimate will be provided before work is performed on instruments that are beyond the warranty period.

If reshipment is necessary, please use the original shipping container. If the original container is not available, be sure that adequate protection is provided to prevent damage during shipment. It is recommended that the instrument be surrounded by at least 3 inches of shock-absorbing material in the shipping container.

Table 3-1. Recommended Test Equipment

INSTRUMENT TYPE	REQUIRED CHARACTERISTICS	RECOMMENDED MODEL
DMM CALIBRATOR	Voltage Range: 0-1000V ac, $\pm 0.05\%$ Frequency Range: 40-10,000 Hz, $\pm 1\%$ Voltage Range: 0-1000V dc, Accuracy: $\pm 0.05\%$ Current Range: 2 mA-2A Accuracy: $\pm 2\%$ Values: 100 ohm, 1 kilohm, 10 kilohm, 100 kilohm, 1 megohm, 10 megohm Accuracy: $\pm 0.05\%$	John Fluke Models 5100B, 5101B, 5102B, 5215A
TRANSCONDUCTANCE AMPLIFIER	Output Range: 1-10A Accuracy: $\pm 1\%$	Fluke Model 5220A

3-3. OPERATOR MAINTENANCE

WARNING

TO AVOID ELECTRICAL SHOCK, REMOVE THE TEST LEADS AND ANY INPUT SIGNALS BEFORE REPLACING THE BATTERY OR FUSES. CLOSE CASE AND REPLACE SCREWS BEFORE USING METER.

3-4. Battery Replacement

NOTE

The Fluke 25 and 27 Multimeters have been designed to meet the requirements of the United States Department of Labor Mine Safety and Health Administration for use in mines. If your instrument has MSHA approval, a decal stating so will be present on the bottom of your instrument. The following WARNING applies only if the decal is present:

WARNING

THE FLUKE 25 AND 27 MULTIMETERS ARE APPROVED (PERMISSIBLE) BY THE UNITED STATES DEPARTMENT OF LABOR MINE SAFETY AND HEALTH ADMINISTRATION (MSHA) FOR USE IN MINES (APPROVAL 2G-3665-0). TO MAINTAIN MSHA PERMISSIBILITY, REPAIRS TO THESE INSTRUMENTS MUST BE MADE USING PARTS EXACTLY LIKE THOSE FURNISHED BY JOHN FLUKE MFG. CO., INC. ANY CHANGES IN THE INTRINSICALLY SAFE CIRCUITRY OR COMPONENTS MAY RESULT IN AN UNSAFE CONDITION.

THE FLUKE 25 AND 27 MULTIMETERS WERE TESTED BY THE MSHA FOR INTRINSIC SAFETY IN METHANE AIR MIXTURES ONLY. THE FLUKE 25 AND 27 MULTIMETERS ARE MSHA APPROVED WITH A 9V NEDA 1604 (CARBON ZINC) BATTERY ONLY. DO NOT USE TO CHECK ELECTRICAL BLASTING CIRCUITS. DO NOT CONNECT TO AN ELECTRICALLY ENERGIZED CIRCUIT IN A HAZARDOUS AREA.

The Fluke 25 and 27 are each powered by a single 9V battery (NEDA 1604, 6F22, or 006P). Referring to the Figure 3-1, use the following procedure to replace the battery:

1. Turn the rotary switch to OFF, and remove the test leads.
2. Lift the instrument stand on the back of the instrument, then remove the four #6 X 32, Pozidriv® screws from the battery cover.
3. Pull the battery cover straight out from the back of the instrument. (A coin-slot in the side of the battery cover facilitates removal.)




Figure 3-1. Battery and Fuse Replacement

4. Remove the battery from the battery holder, then disconnect the battery connector.
5. Snap the battery connector to the terminals on the new battery, then slide the battery into the battery holder. Slip each battery lead into the slot in the holder.
6. Insert the battery holder/cover into the instrument, then start the four screws removed in step 2. Press firmly on the battery cover while tightening the screws in a diagonal pattern.

3-5. Fuse Test

1. Turn the function selector switch to the Ω position.
2. Connect a test lead from the volts/ohms/diode-test input terminal to the A input terminal.
3. The display should indicate between 0.1Ω and 0.3Ω . This tests F3 (15A, 600V fast).
4. Move one end of the test lead from the A input terminal to the mA/ μ A input terminal.
5. The display should indicate between 5.3Ω and 6.0Ω . This tests F1 (3A, 600V fast) and F2 (630 mA, 250V fast).
6. If either of the above display indications is OL (overload), replace the appropriate fuse.

3-6. Fuse Replacement

Referring to Figure 3-1, use the following procedure to check or replace the Fluke 25/27 fuses:

inspection, periodic calibration verification, and as an aid in troubleshooting. If the instrument fails any test, calibration adjustment or repair is needed.

Prior to performing any of the testing procedures, allow the instrument to stabilize to room temperature (18 to 28 degrees Celsius). Also, check the fuses and if the battery annunciator is displayed, change the battery.

NOTE

In the following procedures, the Fluke 25 and 27 are referred to as the unit under test, or UUT.

3-13. Display Test

When the function switch is moved from the OFF position to any other position, the instrument performs a power-up self test. All LCD segments in the display are switched on while the test is in progress, then the instrument commences normal operation. This automatic self test verifies that the instrument is functional and that all LCD segments are functioning.

3-14. Voltage Functions Performance Verification

The following procedure may be used to verify proper operation and calibration of the ac and dc voltage measurement functions. Required test equipment is listed in Table 3-1.

CAUTION

Connect the common terminal of the Digital Multimeter Calibrator to the COM terminal on the UUT.

1. Verify that both the Digital Multimeter Calibrator (hereafter referred to as the DMM Calibrator) and the UUT are off.
2. Connect the UUT, using the volts/ohms/diode-test input terminal, to the ac output connections of the DMM Calibrator.
3. Turn the function switch on the UUT to the ac voltage position (\tilde{V}).
4. Switch on power to the DMM Calibrator, and program it for an output of 2.7V ac, at 100 Hz.
5. Verify that the UUT indicates between 2.684 and 2.716V ac.
6. Program the DMM Calibrator for an output of 27V ac, at 10 kHz.
7. Verify that the UUT indicates between 26.43 and 27.57V ac.

8. Program the DMM Calibrator output for 250V ac, 10 kHz.
9. Verify that the UUT indicates between 244.7 and 255.3V ac.
10. Program the DMM Calibrator for an output of 1000V ac, at 10 kHz.
11. Verify that the UUT indicates between 967 and 1033V ac.
12. Program the DMM Calibrator for an output of zero volts.
13. Turn the UUT function switch to the dc voltage position (\bar{V}).
14. Program the DMM Calibrator output for 2.7V dc.
15. Verify that the UUT indicates between 2.696 and 2.704V dc.
16. Program the DMM Calibrator for an output of 27V dc.
17. Verify that the UUT indicates between 26.96 and 27.04V dc.
18. Program the DMM Calibrator output to 250V dc.
19. Verify that the UUT indicates between 249.6 and 250.4V dc.
20. Program the DMM Calibrator for an output of 1000V dc.
21. Verify that the UUT indicates between 998 and 1002V dc.
22. Switch off the DMM Calibrator. Disconnect the Calibrator from the UUT.

3-15. AC and DC Current Performance Verification

The following procedure may be used to test the ac and dc current functions, and to verify current measurement accuracy.

1. Turn the UUT function switch to the ac mA/A position (\tilde{mA}/A).
2. Connect the DMM Calibrator output to the UUT mA/ μ A input terminal.

7. Lubricate the outer edges of the detent spring (MP5) with a very thin layer of silicon lubricant, then install the detent spring over the rotary switch shaft. Detent spring orientation is not critical.
8. Install the E-ring retainer (MP6) on the rotary switch shaft.
9. Rotate the rotary switch to the upper OFF position.
10. Place the rotary switch extension shaft (MP17) on the rotary switch shaft. Note the small pointer on the base of the extension shaft. Place the pointer toward the center of the display while the rotary switch knob is in the upper OFF position.
11. To reassemble the main pcb/shield assembly, fit the top shield (MP9) over the component side of the pcb, taking care not to bend the connector pins. Make sure the shield posts fit through the holes in the pcb, and verify that the rotary switch is in the upper OFF position.
12. Position the bottom shield (MP3) on the back of the pcb with the stand-offs fitted through the pcb, then position the top shield on the top of the pcb with the molded stand-offs fitted through the pcb.
13. Install the two Phillips-head machine screws (H8) and flat washers through the top shield into the bottom shield. Install the three thread-forming Phillips-head screws (H4) through the bottom shield into the top shield.
14. Carefully fit the main pcb/shield assembly into the top case, taking care to ensure that the connector pins on the main pcb are lined up properly with the connector on the digital pcb, and that the switch shaft extension aligns with the two rotary switch wafers in the OFF position (do not use force). Engage the connector by pressing lightly on the bottom shield at the case screw holes.
15. Install the four Phillips-head machine screws (H3) with lock washers that secure the main pcb/shield assembly to the back of the input terminals, again using a diagonal pattern.
16. Install a new O-ring (MP13) on the bottom case (MP10), if it was not replaced during disassembly, and position it at the beginning of the tapered area.

17. Place the bottom case on the top case, then start four new thread-forming screws (H7) with rubber washers. (The new screws and washers are provided in the seal kit.) Press the case halves firmly together, and using a number 2 Posidriv® screwdriver, tighten the screws in a diagonal pattern (lower-right, upper-left, upper-right, lower left,) to ensure a proper seal.
18. If the battery compartment O-ring (MP15) was not replaced during disassembly, it should be replaced before reassembly. Use the procedure given in step 5 of the disassembly procedure.
19. Connect the battery to the battery terminal connector, then slide the battery into the battery holder (MP16). Place the wires in the slot in the upper edge of the battery holder.
20. Slide the battery holder/cover assembly into the back of the instrument.
21. Start the four screws (H6) that secure the battery cover. Press firmly on the battery cover while tightening the screws in a diagonal pattern using a number 2 Posidriv® screwdriver.
22. Move the rotary switch knob from OFF to any function. All segments of the LCD should illuminate briefly if the instrument has been properly assembled.

3-11. Cleaning

CAUTION

Do not use aromatic hydrocarbons or chlorinated solvents for cleaning. These solutions will react with the plastic materials used in the instrument.

CAUTION

Do not allow the LCD to come in contact with moisture.

Clean the exterior plastic parts using a mild solution of detergent and water on a soft cloth. Clean dust from the pcbs using clean, dry air at low pressure (less than 20 psi). Clean contaminants from the pcbs using isopropyl alcohol and a soft brush, followed by demineralized water and a soft brush (remove the LCD before washing). Dry the pcb at 50 to 60 degrees Celsius for 24 hours after washing (and before reassembly) to assure that no moisture is sealed in the instrument.

3-12. PERFORMANCE TEST

The following procedures allow you to check the performance of the Fluke 25 or 27 against the specifications given in the Fluke 25/27 Operator's Manual. The procedures are recommended for incoming

1. Perform steps 1 through 3 of the battery replacement procedure.
2. Remove the defective fuse (or check continuity through the suspected fuse), and if necessary install a new fuse of the same size and rating. (Remove the battery from the battery holder to gain access to the spare fuse for F2.)
3. Reinstall the battery holder/cover as instructed in step 6 of the battery replacement procedure.

3-7. GENERAL MAINTENANCE INFORMATION

3-8. Handling Precautions For Static-Sensitive Devices

CAUTION

This unit contains CMOS components which can be damaged by static discharge. Static-sensitive components include U1 (the custom analog IC), U2 (the microcomputer), and op amp AR1. To prevent static discharge damage, take the following precautions when servicing the instrument.

- Perform all work at a static-free work station.
- Do not handle components or pcb (printed circuit board) assemblies by their connectors.
- Wear static ground straps.
- Use conductive foam to store components.
- Remove all plastic, vinyl, and styrofoam from the work area.
- Use a grounded, temperature-regulated soldering iron.

3-9. Disassembly

WARNING

TO AVOID THE POSSIBILITY OF ELECTRIC SHOCK, REMOVE THE TEST LEADS PRIOR TO DISASSEMBLY.

CAUTION

Opening the instrument case in damp, humid environments followed by moving the instrument to a cooler environment could cause condensation inside the case. Instrument performance may be adversely affected by condensation.

CAUTION

To avoid contaminating the pcbs with oil from the hands (or O-ring lubricant), handle the pcbs by the edges or wear gloves. If a pcb does become contaminated, refer to the cleaning instructions given later in this section. Do not allow the LCD to come in contact with moisture.

NOTE

Disassembly requires a number 2 Posidriv® screwdriver for all exterior screws and a number 1 Phillips-head screwdriver for all interior screws. Reassembly requires silicone lubricant (Parker Super O-lube is recommended) and new seals. A Fluke seal kit (Model 8025A-7401, Fluke Part Number 738112) provides a complete set of seals and four replacement screws and washers for the bottom case. A 2 oz tube of Parker Super-O-Lube can be obtained from the John Fluke Mfg. Co., Inc. by ordering p/n 812230.

Most maintenance procedures require at least partial instrument disassembly. The following procedure (illustrated in Figure 3-2) provides complete step-by-step disassembly instructions to gain access to any assembly. Complete disassembly is not required to gain access to most assemblies; the following procedure contains notes that explain which maintenance procedures are possible at various levels of disassembly.

1. Turn the function switch to the upper OFF position.
2. Lift the tilt bail up about 1 inch up from the back of the instrument, then gently pull out the ends of the tilt bail and remove it.
3. Remove the four Posidriv® machine screws (H6) that hold the battery cover (MP14) to the bottom case, then lift the battery cover and battery holder out of the instrument.
4. Remove the battery and battery connector from the battery holder, then disconnect the battery.
5. Remove the battery holder from the battery cover by tilting the battery holder toward the non-skid foot and sliding it off the battery cover (away from the non-skid foot). Remove the old O-ring (MP15). Clean the O-ring surfaces of the battery cover and the instrument case. Install the battery holder on the battery cover, then install the new O-ring.
6. Remove the four Posidriv® screws (H7) with rubber washers from the bottom case.
7. Lift the bottom case off the instrument, and remove the O-ring (MP13) between the top and bottom cases. (Always install a new O-ring prior to reassembly.)
8. At this point, all calibration adjustments are accessible through the openings in the side of the pcb shield. Refer to the calibration adjustment procedure later in this section to calibrate the instrument.




Figure 3-2. Disassembly

9. Remove the four Phillips-head screws (H3) at the bottom of the pcb that connect the pcb to the input terminals molded into the top case.
10. Carefully lift the upper end of the main pcb and shield assembly to disconnect the assembly from the digital pcb, then lift the main pcb and shield assembly clear of the case.
11. Note the position of the rotary switch extension shaft (MP17). With the rotary switch in the OFF position, the single small pointer on the base of the extension shaft is pointed toward the top of the instrument. Refer to Figure 3-3.
12. Lift the rotary switch extension shaft (MP17) off the rotary switch shaft (the shaft on MP2).
13. Remove the E-ring retainer (MP6) and the detent spring (MP5) from the rotary switch shaft.
14. Pull the rotary switch knob (MP2) out from the front of the top case (MP1). Take care not to lose the Teflon bearing washer (H1) under the knob.
15. To replace the O-ring (MP4) on the rotary switch shaft, cut off the existing O-ring without scratching the metal shaft. Clean the shaft thoroughly, and slide a new O-ring over the shaft into the groove on the shaft.
16. Remove the four lower Phillips-head screws (H5) that secure the digital pcb to the top case

using a diagonal pattern (i.e., remove the upper-right screw, then the lower-left, then the upper-left, and last the lower-right). Then remove the two Phillips-head screws (H2) at the top of the digital pcb, above the connector.

17. Carefully lift the digital pcb straight up from the top case and remove it.

CAUTION

Do not touch the elastomeric LCD contact strips (MP20) or contacts of the momentary switch (S3-S6) with bare hands. Wear gloves or remove the contact strips using clean pliers or tweezers. Avoid contaminating the contact strips.

18. Lift the momentary switch (S3-S6) from the top case.
19. Remove the elastomeric LCD contact strips (MP20) and the LCD interconnect support (MP18), located on the back of the LCD.
20. Remove the LCD (U3) and the LCD mask (MP19) from the case.
21. To disassemble the main pcb/shield assembly, first remove the two Phillips-head screws (H8) from the top shield (MP9). Take care not to lose the flat washers under the screw heads.
22. Turn the assembly over and remove the three thread-forming, Phillips-head screws (H4) that secure the bottom shield (MP3).




Figure 3-3. Switch Extension Shaft Installation

23. Lay the bottom shield aside, and separate the top shield from the pcb.
24. At this point, all main pcb components are accessible.

3-10. Reassembly

NOTE

Reassembly requires a number 2 Posidriv® screwdriver for all external screws, a number 1 Phillips-head screwdriver for all internal screws, silicone lubricant (Parker Super-O-Lube is recommended), and new seals. A Fluke seal kit (Model 8025A-7401, Fluke Part Number 738112) provides a complete set of seals and four replacement screws and washers for the bottom case. A 2 oz tube of Parker Super-O-Lube can be obtained from the John Fluke Mfg. Co., Inc. by ordering p/n 812230.

Reassembling the instrument is primarily a reversal of the disassembly procedure. However, some precautions are necessary to ensure proper sealing and to maintain watertight integrity. Use the following procedure to reassemble the instrument:

CAUTION

Do not touch the elastomeric LCD contact strips (MP20) or contacts of the momentary switch (S3-S6) with bare hands. Wear gloves or remove the contact strips using clean pliers, or tweezers. Avoid contaminating the contact strips.

1. Position the LCD mask (MP19) in the top case (MP1), then place the LCD (U3) in the LCD

mask with the Fluke part number toward the top of the instrument, pressing the LCD lightly to engage the spring action of the LCD mask. Place the LCD interconnect support (MP18) over the LCD, then place the elastomeric connector strips (MP20) at the top and bottom of the LCD interconnect support with the black connection strip against the LCD.

2. Note the small bump at the center of one edge of the momentary switch (S3-S6). Place the momentary switch in the case with the bump toward the LCD display.
3. Place the digital pcb in the top case with the connector toward the back of the instrument and at the top of the case.
4. Install the four lower Phillips-head screws (H5) that secure the digital pcb over the momentary switch. Note that the momentary switch provides a seal between the case and the digital pcb. Install the screws using a diagonal sequence (i.e., upper-right, then lower-left, then upper-left, then lower-right).
5. Install the two thread-forming, Phillips-head screws (H2) above the connector that hold the top of the digital pcb.
6. Install a new O-ring (MP4) on the rotary switch shaft (if not previously installed), then place the Teflon washer (H1) on the rotary switch shaft, then install the rotary switch knob in the front of the top case.