

# Network Load Balancing Software Administrator's Guide

007-3895-002

---

## CONTRIBUTORS

Written by Carolyn Curtis, with material by Carlin Otto and Susan Thomas and updated by Terry Schultz

Illustrated by Dan Young

Production by Karen Jacobson

Engineering contributions by James Yarbrough, John Becker, and Ken Robinson

---

## COPYRIGHT

© 1999, 2004, Silicon Graphics, Inc. All rights reserved; provided portions may be copyright in third parties, as indicated elsewhere herein. No permission is granted to copy, distribute, or create derivative works from the contents of this electronic documentation in any manner, in whole or in part, without the prior written permission of Silicon Graphics, Inc.

---

## LIMITED RIGHTS LEGEND

The software described in this document is “commercial computer software” provided with restricted rights (except as to included open/free source) as specified in the FAR 52.227-19 and/or the DFAR 227.7202, or successive sections. Use beyond license provisions is a violation of worldwide intellectual property laws, treaties and conventions. This document is provided with limited rights as defined in 52.227-14.

---

## TRADEMARKS AND ATTRIBUTIONS

Silicon Graphics, SGI, the SGI logo, CHALLENGE, Indy, IRIS, and IRIX are registered trademarks and Indigo2, O2, OCTANE, Onyx2, Origin2000, Origin200, and Origin200 GIGAchanel are trademarks of Silicon Graphics, Inc., in the United States and/or other countries worldwide. ACEswitch is a trademark of Alteon Networks, Inc. EtherChannel and Catalyst are registered trademarks of Cisco Systems, Inc. Macintosh is a registered trademark of Apple Computer, Inc. Windows NT is a registered trademark of Microsoft Corporation. All other trademarks mentioned herein are the property of their respective owners.

---

## What's New in This Guide

This rewrite of the *Networking Load Balancing Software Administration's Guide* supports the 6.5.24 release (or later) of the IRIX operating system.

### Major Documentation Changes

This manual provides information about the following:

- Expanded description of Network Load Balancing Software failure detection and recovery functionality in “Network Load Balancing Software Features” on page 1.
- Updated information in “Preparing for Network Load Balancing Software Configuration” on page 9.
- Revised information in “Configuring the Network Load Balancing Software and Driver” on page 13.
- Added information about how to configure your system for multiple Ethernet ports in “Adding Network Load Balancing to a System” on page 14.
- Added descriptions of the tuning parameters for Network Load Balancing Software failure detection and recovery in “Tuning Parameters for Failure Detection and Recovery” on page 27.



---

## Record of Revision

<b>Version</b>	<b>Description</b>
001	March 1999 Original publication.
002	August 2004 Updated to support IRIX 6.5.24 or later.



---

# Contents

<b>Figures</b>	ix
<b>Tables</b>	xi
Audience	.xiii
Structure of This Document	.xiii
Other Required Documentation	.xiv
Conventions	. xv
Obtaining Publications	. xv
Reader Comments	.xvi
<b>1. Network Load Balancing Software and the Ethernet</b>	<b>1</b>
Network Load Balancing Software Features	1
Compatibility	2
Supported Platforms	3
Supported Switches and Ethernets	3
Network Load Balancing Driver and System Resources	6
<b>2. Network Load Balancing Software Installation and Configuration</b>	<b>7</b>
Installing the Software	7
IP Addresses and the Network Load Balancing Software	8
Preparing for Network Load Balancing Software Configuration	9
Network Load Balancing Software and the Shell Command File <code>/etc/init.d/network</code>	12
Configuring the Network Load Balancing Software and Driver	13
Adding Network Load Balancing to a System	14
Making the Network Load Balancing Interface the Primary Interface	18
Configuring Multiple Network Load Balancing Software Interfaces	21
Verifying the Network Load Balancing Software Connection	22
<b>3. Performance Tuning</b>	<b>25</b>
Tuning Parameters	25

Tuning Parameters for Failure Detection and Recovery . . . . .	.27
Changing Input Load Balancing . . . . .	.28
Adjusting the Balance Period. . . . .	.29
Adjusting the Balance Threshold Value. . . . .	.29
Adjusting the Average Weight . . . . .	.29
<b>4. Troubleshooting . . . . .</b>	<b>.31</b>
Initial Remedies. . . . .	.31
Connection Has Not Been Functional Since Last Boot . . . . .	.32
Connection Has Been Functional in the Recent Past . . . . .	.33
High Rate of Packet Loss Occurs . . . . .	.34
System Cannot Communicate With Other Systems . . . . .	.35
System Does Not Load Miniroot or Boot From the Network . . . . .	.35



---

# Figures

<b>Figure 1-1</b>	Network Load Balancing Software Example . . . . .	5
<b>Figure 2-1</b>	Network Load Balancing Device as Secondary Interface Example ( <code>netstat -in</code> ) . . . . .	18
<b>Figure 2-2</b>	Network Load Balancing Device as Primary Interface Example ( <code>netstat -in</code> ) . . . . .	21
<b>Figure 4-1</b>	Displaying Available Interfaces With <code>netstat -in</code> . . . . .	33



---

## Tables

<b>Table 1-1</b>	Network Load Balancing Software Subsystems . . . . .	6
<b>Table 2-1</b>	Default Network Interface Parameters . . . . .	11
<b>Table A-1</b>	Validated Ethernet Switches . . . . .	37



---

## About This Guide

This guide describes the Network Load Balancing Software (NLBS) from Silicon Graphics, Inc., which lets you consolidate Ethernet ports into a single IP address. It also optimizes performance by determining and setting the load balance for input and output packets. The Network Load Balancing Software runs on CHALLENGE, SGI Origin 200, SGI Origin 2000, Silicon Graphics Onyx2, SGI Origin 300, Origin 350, and SGI Origin 3000 system, and SGI Origin 3900 systems running IRIX 6.5 or later.

### Audience

This manual is your guide to configuring, testing, and monitoring your Network Load Balancing Software network connection. This guide has been written so you can perform all the basic Network Load Balancing Software administration tasks.

This guide is written for network system administrators. It presumes general knowledge of the Ethernet and of the Silicon Graphics system in which it is installed.

---

**Note:** This guide is not an in-depth network administration guide; it does not provide information for planning, managing, and maintaining an Ethernet network.

---

### Structure of This Document

This guide consists of the following chapters and appendixes:

- Chapter 1, “Network Load Balancing Software and the Ethernet,” describes the software’s features.
- Chapter 2, “Network Load Balancing Software Installation and Configuration,” explains how to install the software and how to associate Ethernet ports with it.

- Chapter 3, “Performance Tuning,” explains how to tune parameters to control how the Network Load Balancing Software distributes outbound packets, and how it balances inbound packets.
- Chapter 4, “Troubleshooting,” describes what to do when your network connection has problems.
- Appendix A, “Validated Ethernet Switches”, summarizes Ethernet switches for which the Network Load Balancing Software has been validated.
- Appendix B, “Error Messages”, lists Network Load Balancing Software error messages and gives suggestions for remedies.

## Other Required Documentation

For instructions on configuring a system for networking, see the latest version of *IRIX Admin: Networking and Mail*.

For general information about your Silicon Graphics system, see its owner’s guide.

If you do not have your owner’s guide handy, you can get it and other Silicon Graphics documentation online in the following locations:

- If you have installed the guide on your system, or if it is installed on a server on the network, you can use the IRIS InSight Library: from the Toolchest, choose **Help > Online Books > SGI EndUser** or **SGI Admin**, and select the applicable owner’s or hardware guide.
- If you have access to the Internet, you can use the Technical Publications Library. Enter the following URL in your Web browser location window:  
<http://docs.sgi.com>

Once you are in the library, choose **Catalogs > Hardware Catalog >** and look under the **Owner’s Guides** for the applicable owner’s guide.

## Conventions

The following conventions are used throughout this document:

Convention	Meaning
<code>command</code>	This fixed-space font denotes literal items such as commands, files, routines, path names, signals, messages, and programming language structures.
<i>variable</i>	Italic typeface denotes variable entries and words or concepts being defined.
<b>user input</b>	This bold, fixed-space font denotes literal items that the user enters in interactive sessions. Output is shown in nonbold, fixed-space font.
[]	Brackets enclose optional portions of a command or directive line.
...	Ellipses indicate that a preceding element can be repeated.
manpage(x)	Man page section identifiers appear in parentheses after man page names.

## Obtaining Publications

You can obtain SGI documentation in the following ways:

See the SGI Technical Publications Library at <http://docs.sgi.com>. Various formats are available. This library contains the most recent and most comprehensive set of online books, release notes, man pages, and other information.

If it is installed on your SGI system, you can use InfoSearch, an online tool that provides a more limited set of online books, release notes, and man pages. With an IRIX system, select **Help** from the Toolchest, and then select **InfoSearch**. Or you can type `infosearch` on a command line.

You can also view release notes by typing either `grelnotes` or `relnotes` on a command line.

You can also view man pages by typing `man <title>` on a command line.

## Reader Comments

If you have comments about the technical accuracy, content, or organization of this document, contact SGI. Be sure to include the title and document number of the manual with your comments. (Online, the document number is located in the front matter of the manual. In printed manuals, the document number is located at the bottom of each page.).

You can contact SGI in any of the following ways:

- Send e-mail to the following address:  
techpubs@sgi.com
- Use the Feedback option on the Technical Publications Library web page:  
<http://docs.sgi.com>
- Contact your customer service representative and ask that an incident be filed in the SGI incident tracking system.
- Send mail to the following address:  
Technical Publications  
SGI  
1500 Crittenden Lane, M/S 535  
Mountain View, California 94043-1351

SGI values your comments and will respond to them promptly.



# Network Load Balancing Software and the Ethernet

The Network Load Balancing Software lets you consolidate as many as 40 Ethernet ports into a single IP address, and balance the load on the ports.

This chapter consists of these sections:

- “Network Load Balancing Software Features” on page 1
- “Compatibility” on page 2
- “Network Load Balancing Driver and System Resources” on page 6

## Network Load Balancing Software Features

The Network Load Balancing Software acts as a virtual network device, with its own IP address.

You associate real devices—the actual Ethernet ports—with the Network Load Balancing Software; instead of using and advertising the ports’ IP addresses, you use the Network Load Balancing Software’s IP address. The Network Load Balancing Software and its ports look like a single device to the clients.

The method of assigning a single IP address to a group of Ethernet devices is to collect the Ethernets under a new network device, the *load-balancing device*. Each Ethernet device must have its own IP address, and this address cannot be identical to that of any other network device on the system. Only the IP address of the load-balancing device is advertised, typically through the name assigned to the IP address; the IP addresses of the individual Ethernets are not.

Besides offering the efficiency of a single IP address for several ports, the Network Load Balancing Software automatically optimizes load sharing:

- The Network Load Balancing Software distributes outbound packets on a per-connection basis. (Packets with the same source and destination IP addresses

and port numbers are considered to belong to the same connection.) It guarantees that all packets for a single connection are sent out on the same Ethernet device.

- The Network Load Balancing Software balances input on a per-client basis. Input balancing is dynamic and requires no special configuration.

Each client is given a MAC address to use for the IP address belonging to the load-balancing device. The clients do not all have the same IP-to-MAC address mapping; thus they send all of the packets they transmit to the MAC address they were given without regard to connection.

You can adjust parameters to fine-tune the load balancing; this process is explained in Chapter 3, “Performance Tuning.”

The Network Load Balancing Software can detect link failure and can reconfigure the load-balancing device in real time to adapt for the failed link. The software can detect interface and cable failure between the server and the switch; it automatically redirects inbound and outbound traffic to an active adapter port, thus eliminating a single point of network failure. It is completely transparent to the application, regardless of the protocol it uses with the exception that user datagram protocol (UDP) applications which may encounter a packet drop. As packet dropping is to be expected for UDP in this case, the failure of a link does not alter the expected behavior of UDP.

In the event of link failure, no administration action is required. The time it takes for Network Load Balancing Software to recover depends upon network activity and the settings of the tuning parameters for Network Load Balancing Software detection and recovery. These primary tuning parameters are described in “Tuning Parameters for Failure Detection and Recovery” on page 27 and the `n1b(7)` man page and `/var/sysgen/mtune/if_lb` file.

Currently, you can not reconfigure Network Load Balancing Software devices using the `network stop` followed by `network start` commands. You must reboot. For more information on the `network` script, see the `network(1M)` man page.

## Compatibility

This section discusses compatibility in the following subsections:

- “Supported Platforms” on page 3
- “Supported Switches and Ethernets” on page 3

The Network Load Balancing Software provides IP alias support and dynamic session shifting. As you can with any network device, you can set up aliases for the Network Load Balancing Software; follow instructions in the latest version of *IRIX Admin: Networking and Mail*. However, you cannot assign aliases to the physical devices.

## Supported Platforms

The Network Load Balancing Software runs on the following Silicon Graphics systems:

- Challenge DM, L, and XL system with at least one two-port Fast Ethernet VME adapter board installed
- Origin 200 system with up to three PCI Fast Ethernet adapter boards per module
- Origin 200 GIGAchannel two-module system with two Gigabit Ethernet PCI adapter boards or with up to five 4-port XIO Fast Ethernet adapter boards
- Origin 2000 or Onyx2 system with up to six 4-port Fast Ethernet adapter boards per module, or with two to six Gigabit Ethernet adapter boards per module
- Origin 300 system with up to three PCI Fast Ethernet adapter boards per module
- Origin 350 system with up to three PCI Fast Ethernet adapter boards per module
- Origin 3000 system with up to six 4-port Fast Ethernet adapter boards per module, or with two to six Gigabit Ethernet adapter boards per module
- Origin 3900 system with up to six 4-port Fast Ethernet adapter boards per module, or with two to six Gigabit Ethernet adapter boards per module

In addition, the Network Load Balancing Software is interoperable with OCTANE, O2, Indy, Indigo2, Fuel, Tezro and any other client that supports gratuitous ARP.

## Supported Switches and Ethernets

The Network Load Balancing Software supports load distribution and bandwidth aggregation for mixed IP traffic, that is, multiple connections, or connections to multiple hosts.

A network switch is required as an interface between the client Ethernet ports and the host system running the Network Load Balancing Software. The Ethernets used with the load-balancing device must be connected to a Layer 2 switch and must be on the same virtual local area network (VLAN). There are no additional requirements for the switch,

nor are there any requirements for any other systems connected to the switch to send packets to the load-balancing device. No special switch configuration is required for Layer 2 devices.


The software is compatible with Ethernet 10-Base-T, 100-Base-T, gigabit Ethernet and . The Network Load Balancing Software supports 2 to 40 Ethernet ports per subnet, and 1 to 20 load-balancing devices per system, assuming two ports minimum per group. Appendix A, “,” summarizes Ethernet switches with which the Network Load Balancing Software has been validated.

---

**Note:** No speed information is made available by the Ethernet driver, so the device does not distinguish between 10-Base-T, 100-Base-T, Gigabit Ethernet, and 10-Gbit Ethernet. Because the load-balancing device does not take maximum line bandwidth into account (that is, bandwidth differences between attached devices), mixing 10-Base-T, 100-Base-T, and gigabit Ethernet might not give the expected results.

---

Figure 1-1 diagrams an example of Network Load Balancing Software and switch topology.



**Figure 1-1** Network Load Balancing Software Example

---

**Note:** For more information on networks on Silicon Graphics systems, see the latest version of *IRIX Admin: Networking and Mail*.

---

## Network Load Balancing Driver and System Resources

The Network Load Balancing driver includes the subsystems summarized in Table 1-1.

**Table 1-1** Network Load Balancing Software Subsystems

Subsystem	Description	Approximate Size (512-Byte Blocks)
<code>nlb_eoe.sw.nlb</code>	Network Load Balancing driver software	116
<code>nlb_eoe.man.nlb</code>	Man pages	12
<code>nlb_eoe.man.relnotes</code>	Release notes	32
<code>nlb_eoe.books</code>	Network Load Balancing Software Administrator's Guide (accessible online if Insight books are loaded)	

The Network Load Balancing Software places an additional memory usage load of 40 bytes per client on the kernel: each client communicating with the server via the server's load-balancing interface causes the server to allocate 40 bytes of memory. This amount remains allocated as long as the route entry exists. When the client is no longer sending packets, the route entry is eventually removed due to an ARP entry expiration.

The worst-case cost of balancing the input load is three ARP packets (one request, one reply, and one gratuitous request) per balance period. By default, this period is one second, so the cost for the default would be three packets per second. This overhead does not appear to have any measurable effect.

# Network Load Balancing Software Installation and Configuration

This chapter describes how to configure the Network Load Balancing Software, in these sections:

- “Installing the Software” on page 7
- “IP Addresses and the Network Load Balancing Software” on page 8
- “Preparing for Network Load Balancing Software Configuration” on page 9
- “Network Load Balancing Software and the Shell Command File `/etc/init.d/network`” on page 12
- “Configuring the Network Load Balancing Software and Driver” on page 13
- “Adding Network Load Balancing to a System” on page 14
- “Making the Network Load Balancing Interface the Primary Interface” on page 18
- “Configuring Multiple Network Load Balancing Software Interfaces” on page 21
- “Verifying the Network Load Balancing Software Connection” on page 22

## Installing the Software

Use the `inst(1M)` command to install the Network Load Balancing Software. (For information on using `inst`, see *IRIX Admin: Software Installation and Licensing* in the Technical Publications Library.)

If you are installing the Network Load Balancing Software for the first time, the subsystems marked `default` are the ones that are installed if you use the `go` command from the `Inst` menu.

To install a different set of subsystems, use the `install`, `remove`, `keep`, and `step` commands in `inst` to customize the list of subsystems to be installed, then choose `go`.

## IP Addresses and the Network Load Balancing Software

Your system must have an *IP address* and a *network connection name* for each Network Load Balancing Software Network Load Balancing Software network interface and for each device to be assigned to the Network Load Balancing Software.

- IP addresses are usually assigned by a site's network administrator, who obtains them from the Network Information Center.
- The network connection name is entered in the `/etc/hosts` file<sup>1</sup>. This name is paired with an IP address. Each network interface must have one network connection name that is unique to the domain and one globally unique IP address. The following example line that might appear in an `/etc/hosts` file shows an IP address (from the test network, 192.2.0) and a network connection name, followed by its short form (or alias).

```
192.0.2.5 sys2.mrktg.group1.com sys2
```

Generally, network interface IP addresses must always be unique and cannot share a subnet on the same system. (For more information, see information on IP addresses in the latest version of *IRIX Admin: Networking and Mail*.)

However, network devices assigned to a Network Load Balancing Software device can share a subnet address with the Network Load Balancing Software device or the other network devices assigned to it. For Network Load Balancing Software, these addresses must be unique only within the subnet.

The IP addresses for network devices assigned to a Network Load Balancing Software device must be addresses that can legally appear on the wire. Although these addresses are not used or advertised, they appear in ARP packets.

These addresses need not be on the same network or subnet as the Network Load Balancing Software; you can reuse addresses currently in use on other subnets.

The IP addresses of the devices configured for load balancing and that of the Network Load Balancing Software need not be related, however, if there are multiple systems with Network Load Balancing Software interfaces on the same subnet, all of the attached

---

<sup>1</sup> For more information about the `/etc/hosts` file, see the `hosts(4)` man page and *IRIX Admin: Networking and Mail*.



Ethernet devices for all of these Network Load Balancing Software systems must also have IP addresses on the same subnet as the Network Load Balancing Software devices for the systems to be able to communicate with each other using Network Load Balancing Software.

If there are multiple systems with Network Load Balancing Software interfaces on the same subnet, all of the attached Ethernet devices for these systems must also have IP addresses on the same subnet as the Network Load Balancing Software devices for the systems to be able to communicate with each other using Network Load Balancing Software. When properly configured, the systems will be able to communicate with each other, but there will be no effective increase in the bandwidth between them.

The network portion of the IP address for each local area network must be unique; you cannot use the same network address for your system's Ethernet and Network Load Balancing connections.

To get IP addresses for the Network Load Balancing Software and the devices you are associating with it, follow these steps:

1. Determine which real devices you are associating with the Network Load Balancing Software.
2. Obtain an IP address for the Network Load Balancing Software. This address must be unique.
3. Obtain IP addresses for the real (Ethernet) devices if they have not already been assigned.
4. If necessary, configure the Ethernet devices with `ifconfig`. For information on this command, see its man page, `ifconfig(1M)`.

---

**Note:** For specifics, see the sections on planning and setting up a network in the latest version of *IRIX Admin: Networking and Mail*.

---

## Preparing for Network Load Balancing Software Configuration

Before starting Network Load Balancing Software configuration, collect the necessary information and perform housekeeping so that the process goes smoothly. Follow these steps:

1. Determine the number of networks to which your system will be connected after the Network Load Balancing Software is installed.
2. If the system is to have more than one network connection, decide which will be the *primary network*. The primary network interface should be the one where all or most of the system's network services or clients reside.

---

**Note:** If your system must boot over the network, the Network Load Balancing Software connection cannot be the primary network interface. You can not use DHCP to define/create the Network Load Balancing Software interface, it has to be statically configured

---

3. For each network connection, select a network connection name and IP address. The network connection name of the primary network connection must be the same as the system's hostname. You can display your system's hostname by using the `hostname` command within a shell window:

```
% /usr/bsd/hostname
```

You can display the current IP address associated with the network connection name *hostname* by typing one of the following commands in a shell window:

```
% /sbin/grep hostname /etc/hosts
```

```
% /usr/bin/ypmatch hostname hosts
```

The names you create for non-primary network interfaces can be anything you want. To facilitate recognition, the names usually include both the hostname and an indication of the protocol (for example, *nlb-mars* or *nlb2-mars*).

4. Determine if any of your system's network interfaces require special configuration for the *subnet mask (netmask)*, *broadcast address*, and *route metric*.

Table 2-1 summarizes the default operational parameters for the network interfaces.

**Table 2-1** Default Network Interface Parameters

Parameter	Default	Description
Netmask	No subnet. That is, the bits in the standard network portion of the Internet address are set to 1; the bits in the standard host portion of the Internet address are set to 0 (for class B addresses, 0xFFFF0000; for class C, 0xFFFFF000). The netmasks for all of the Ethernet devices to be attached to Network Load Balancing Software devices should be set to 0xffffffff to avoid routing problems.	32-bit value used to create two or more subnetworks from a single Internet address, by increasing the number of bits used as the network portion and decreasing the number of bits used as the host portion. When creating the mask, assign 1 to each network bit and 0 to each host bit.
Broadcast address	For the Internet address family, the host portion of the IP address is set to 1s (for class B addresses, <i>x.x.255.255</i> ; for class C addresses, <i>x.x.x.255</i> ).	Address used by this interface for contacting all systems on the local area network.
Route metric	0	Hop count value advertised by the routing daemon ( <i>routed</i> ) to other routers. Higher numbers make the route less desirable and less likely to be selected as a route. Settings range from 0 (most favorable) to 16 (least favorable, infinite).
arp	Address Resolution Protocol (ARP) is enabled and used by the interface.	Address Resolution Protocol translates IP addresses to link-layer (hardware) addresses. When this parameter is disabled, the interface does not use ARP.
debug	Disabled	When debugging is enabled, a wider variety of error messages is displayed when errors occur.

If any of these operational parameters needs special configuration, you must create or edit an `/etc/config/ifconfig-#.options` file, where the pound sign (#) matches the network interface's order in the `netif.options` file. For example, for the `netif.options` line `if3name=lb0`, create or edit the file `/etc/config/ifconfig-3.options`.

Insure that the proper `/etc/config/ifconfig-#.options` file specifies the correct subnetwork mask for the associated network.

For complete instructions for configuring operational parameters, see the device configuration instructions in *IRIX Admin: Networking and Mail*.

5. Update the site's hosts and ethers databases to include the correct information about this system.

## Network Load Balancing Software and the Shell Command File

### `/etc/init.d/network`

During system startup and any time it is invoked specifically, the shell command file `/etc/init.d/network` configures and initializes the network interfaces and software. Some of the script's procedures are accomplished by calling other utilities and reading configuration files. Among other tasks, `/etc/init.d/network` performs the following:

- Determines the system's hostname, as defined in the `/etc/sys_id` file.
- Determines the network hardware and interfaces available in the operating system.

This information can be viewed with the `hinv` command.

- Determines the ordering for the network interfaces.

This information is defined in the `/etc/config/netif.options` file. If the `netif.options` file has not been altered, the default ordering is configured (as defined in the `network` script).

- Determines the network connection name for each network interface.

This information is defined by the `if#name` lines in the `/etc/config/netif.options` file. If the `netif.options` file has not been altered, the default names (as defined in the `network` script) are used.

- Determines the IP address for each interface by looking up each network connection name in the `/etc/hosts` file.
- Determines the settings for each network interface's operational parameters.

This information is defined in the `/etc/config/ifconfig-#.options`. If an `ifconfig-#.options` file does not exist for the interface, the default settings are assigned.

- Configures and starts (enables) the number of network interfaces specified by the *if\_num* variable in the network script.
- Invokes `/etc/init.d/network.ls`, which handles the device-specific configuration of the load-balancing devices.

The results of the *network* script's configuration can be viewed with the `/usr/etc/netstat -i` and `/usr/etc/ifconfig` commands.

## Configuring the Network Load Balancing Software and Driver

This section describes how to configure a new network load-balancing network connection for a system with multiple functional Ethernet connections. Configuration consists of assigning Ethernet devices to the network load-balancing device and performing the normal network device configuration for it. Follow these steps:

---

**Note:** You may want to define the `lb0` interface BEFORE any of the physical interfaces that make it up. For example, if `lb0` is made up of `ef0`, `ef1` and `ef2`, define `lb0` first, `ef0`, then `ef1` and so on. If you do this, Network Load Balancing Software comes up with no incorrect or extra routes that can degrade performance.

---

1. Edit `/etc/config/nlb.options` to assign the Ethernet devices for which load balancing is to be performed. This file initially contains the following lines:

```
lb1name=lb0
lb1devs=
lb_num=1
```
2. To configure one network load-balancing device on the system, set the shell variable *lb1devs* to a comma-separated list of Ethernet devices to be attached to the network load-balancing device `lb0`. For example, if four Ethernet devices in the system, `ef1`, `ef2`, `ef3`, and `ef4` are to be assigned to the network load-balancing device, *nlb.options* looks like the following:

```
lb1name=lb0
lb1devs=ef1,ef2,ef3,ef4
lb_num=1
```

---

**Note:** The *lb1devs* shell variable comma-separated list **cannot** contain leading spaces, tabs, or white spaces. If it does, on start up the circuits will not aggregate and an error message similar to the following appears: Configuring Network Load Balancing devices /etc/init.d/network[587]: ef2,: not found

---

If the *lb0* device has been gartered once, it will re-gartered regardless of the above error. However, on an initial install it will **not** aggregate if spaces are present in the *nlb.options lb1devs* list.

## Adding Network Load Balancing to a System

This section provides instructions for adding a Network Load Balancing device to a system with previously configured Ethernet devices. In these instructions, one of the existing Ethernet interfaces serves as the primary network interface; the Network Load Balancing interface serves as the secondary network interface.

---

**Note:** If your site uses an NIS service, the changes described in this section must also be made to the database on the NIS server.

---

Follow these steps:

1. Make sure you have completed preliminary steps:
  - Obtain network connection names and IP addresses for each Network Load Balancing Software network interface, as described in “IP Addresses and the Network Load Balancing Software” on page 8.
  - Prepare for configuration, as described in “Preparing for Network Load Balancing Software Configuration” on page 9.
  - Configure the software and driver, as described in “Network Load Balancing Software and the Shell Command File /etc/init.d/network” on page 12.
2. If necessary, determine your system’s hostname:

```
# /usr/bsd/hostname
```
3. As superuser, open the */etc/hosts* file and find the line containing your system’s hostname. This line configures your system’s Ethernet network interface. For multiport Ethernet configuration, see step 4.

If you find the Network Load Balancing Software name or address, verify that the IP address and the name are correct for the Network Load Balancing Software connection.

If you do not find an entry for this name, search for the Network Load Balancing Software IP address. Searching for all instances of the system's hostname usually identifies all the network connection names for the system.

If the line is not correct or is missing, edit the file so that there is a line containing the IP address and network connection name for the Network Load Balancing Software network interface.

A typical format for an entry in `/etc/hosts` file is as shown:

*IPaddress full\_network\_connectionname alias*

For example, a portion of an `/etc/hosts` file might look like this, where the host `sys2` has two entries and `sys3` has one:

```
192.0.2.1 sys3.mrktg.group1.com sys3
192.0.2.5 sys2.mrktg.group1.com sys2
192.0.2.8 nlb-sys2.engr.group1.com nlb-sys2
```

4. To configure your system for multiple Ethernet ports, edit the `/etc/hosts` similar to the following example:

```
# Default IP address for a new IRIS. It should be changed
immediately to
# the address appropriate for your network.
# (The '192.0.2' network number is the officially blessed 'test'
network.)

134.16.229.48 sqns3.engr.sgi.com sqns3

# This entry must be present or the system will not work.
127.0.0.1 localhost
#
# lb0: interfaces
#
165.154.216.30 nlb-sqns3.engr.sgi.com nlb-sqns3
165.154.216.31 nlb1-sqns3.engr.sgi.com nlb1-sqns3
165.154.216.32 nlb2-sqns3.engr.sgi.com nlb2-sqns3
165.154.216.33 nlb3-sqns3.engr.sgi.com nlb3-sqns3
165.154.216.34 nlb4-sqns3.engr.sgi.com nlb4-sqns3
```

Edit the `/etc/config/netif.options` similar to the following example:

```
if1name=ef0
if1addr=$HOSTNAME

if5name=ef1
if5addr=nlb1-$HOSTNAME
if6name=ef2
if6addr=nlb2-$HOSTNAME
if7name=ef3
if7addr=nlb3-$HOSTNAME
if8name=ef4
if8addr=nlb4-$HOSTNAME
if9addr=nlb-$HOSTNAME
```

Edit the `/etc/config/nlb.options` similar to the following example:

```
lb1name=lb0
lb1devs=ef1,ef2,ef3,ef4
lb_num=4
```

5. If your system uses more than one network connection, for each one (in addition to Network Load Balancing Software), verify that the name and IP address are the correct; follow instructions in step 3.
6. Copy the line containing your system's hostname and place the copy immediately below the original in the `/etc/hosts` file. This new line configures your system's Network Load Balancing network interface.
7. On the new line, change each instance of your system's hostname to `nlb-hostname`. That is, precede your system's hostname with `nlb-`.
8. On the same (new) line, change the address (digits on the left) to the Network Load Balancing IP address.

For example, the lines for a system with a hostname of `sys3` in the domain `group1.com` looks like this:

```
x.x.x.x sys3.group1.com sys3 #Ether primary
x.x.x.x nlb-sys3.group1.com nlb-sys3 #Load Bal. secondary
```

In these entries, each `x` represents one to three digits.

9. Save and close `/etc/hosts`.
10. Edit `/etc/config/netif.options` so that the network startup script can configure the load-balancing devices. Find the first two pairs of lines showing interface names that are not currently occupied.

In the following example, the first two pairs are in use:



```
if1name= ef0
if1addr=$HOSTNAME
if2name= ef1
if2addr=gate-$HOSTNAME
: if3name=
: if3addr=gate2-$HOSTNAME
: if4name=
: if4addr=gate3-$HOSTNAME
```

In this case, you change

```
: if3name=
: if3addr=gate2-$HOSTNAME
```

to

```
if3name= lb0
if3addr=nlb-$HOSTNAME
```

---

**Note:** Make sure the names or name formats you enter correspond to entries in the `/etc/hosts` file.

---

If this file has, for example, five pairs of entries for five Ethernets already configured on the system, you would add the following two lines below those entries:

```
if6name=lb0
if6addr=nlb-$HOSTNAME
```

---

**Note:** You do not need to edit the entries for the existing Ethernet interfaces. Each Ethernet to be attached to the Network Load Balancing device must have an IP address assigned, even though these addresses are not actually used. You might need to change the addresses of client systems previously on the subnets accessed via the Ethernets that are being assigned to the Network Load Balancing interface.

---

11. Save and close `/etc/config/netif.options`.
12. If applicable, edit `/etc/config/nlb.options` to attach additional Ethernets to the Network Load Balancing device. (See “Configuring the Network Load Balancing Software and Driver” on page 13 for information on this file.)
13. Build your changes into the operating system:

```
# /etc/autoconfig
Automatically reconfiguring the operating system.
```

**Note:** When setting up Network Load Balancing software, you can edit `etc/config/nlb.options` or `/etc/config/netif.options` as appropriate and then apply all of your changes using the `autoconfig` command.

14. Turn on the Network Load Balancing Software using `chkconfig`.
15. Reboot the system to start using the reconfigured kernel.

Once the system is rebooted, output from `netstat -in` might look like that in Figure 2-2.

	Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs	Coll
Ethernet interface	ef0	1500	192.1.2	192.1.2.1	34220311	0	1945959	0	0
Network Load Balancing interface (configured as secondary interface)	lb0	1500	192.0.2	192.0.2.3	3278730	0	801457	0	0
Devices attached to lb0	ef1	1500	192.0.2.6	192.0.2.6	1085717	0	645275	0	0
	ef2	1500	192.0.2.13	192.0.2.13	731025	0	155986	0	0
	ef3	1500	192.0.2.17	192.0.2.17	731025	0	66	0	0
	ef4	1500	192.0.2.25	192.0.2.25	730963	0	130	0	0
	lo0	32992	127	127.0.0.1	1517780	0	1517780	0	0

	Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs	Col
Ethernet interface	ef0	1500	192.1.2	192.1.2.1	34220311	0	1945959	0	
Network Load Balancing interface (configured as secondary interface)	lb0	1500	192.0.2	192.0.2.3	3278730	0	801457	0	
Devices attached to lb0	ef1	1500	192.0.2.6	192.0.2.6	1085717	0	645275	0	
	ef2	1500	192.0.2.13	192.0.2.13	731025	0	155986	0	
	ef3	1500	192.0.2.17	192.0.2.17	731025	0	66	0	
	ef4	1500	192.0.2.25	192.0.2.25	730963	0	130	0	
	lo0	32992	127	127.0.0.1	1517780	0	1517780	0	

**Figure 2-1** Network Load Balancing Device as Secondary Interface Example (`netstat -in`)

## Making the Network Load Balancing Interface the Primary Interface

This section provides instructions for configuring a system so that the Network Load Balancing connection serves as the primary network interface and an Ethernet interface serves as the secondary one.

Follow these steps:

1. Open a shell window and log in as superuser.
2. If necessary, determine your system's hostname:  

```
# /usr/bsd/hostname
```
3. Open the `/etc/hosts` file and find the line containing your system's hostname.  
 If the file does not contain a line for your hostname, enter it; for example:  

```
192.0.2.1 sys3.mrktg.group1.com sys3
```
4. Copy the line and place the copy immediately below the original.
5. On the original line, change the address (the digits on the left) to the IP address for the Network Load Balancing network. This line configures your system's Network Load Balancing network interface. Do not change the hostname.
6. On the new line, change the hostname to the new connection name, which is used for the original primary Ethernet (such as `gate5-sys3` in the example below).

On this new line, do not change the IP address (which represents the Ethernet connection).

The following example shows entries in `/etc/hosts` for a system with a hostname of `sys3` in the domain `group1.com`:

```
x.x.x.x sys3.group1.com sys3 #NLBS primary
x.x.x.x gate5-sys3.group1.com gate5-sys3 #Ether secondary
x.x.x.x gate1-sys3.group1.com gate1-sys3 #NLBS attached to lb0
x.x.x.x gate2-sys3.group1.com gate2-sys3 #NLBS attached to lb0
x.x.x.x gate3-sys3.group1.com gate3-sys3 #NLBS attached to lb0
x.x.x.x gate4-sys3.group1.com gate4-sys3 #NLBS attached to lb0
```

In this example, each `x` represents one to three decimal digits.

7. Save and close `/etc/hosts`.  
 If your site uses an NIS service, the changes described above must also be made to the database on the NIS server.
8. Open the `/etc/config/netif.options` file.  
 Any Network Load Balancing Software device listed in `/etc/config/netif.options` must appear after the Ethernets that are to be attached to it. For example, you might be attaching `ef1` and `ef2` to `lb0`, so they might appear as follows:

```
if2name=ef1
if2addr=gate-$(HOSTNAME)
if3name=ef2
```

```
if3addr=gate2-$(HOSTNAME)
if4name=lb0
if4addr=nlb-$(HOSTNAME)
```

where *NLBinterface* is the name of the Network Load Balancing interface. For example:

```
if4name=lb0
if4addr=nlb-$(HOSTNAME)
```

9. To make an Network Load Balancing Software device be the primary, you have to use the appropriate `/etc/config/ifconfig-*.options` file. In the example above, you can make `lb0` the primary interface by adding the `ifconfig(1M)` keyword `primary` to `/etc/config/ifconfig-4.options`. For example, the `ifconfig-4.options` file might contain the following:

```
netmask 0xffffffff00 primary
```

10. Save and close `/etc/config/netif.options`.
11. If applicable, edit `/etc/config/nlb.options` to attach additional Ethernets to the Network Load Balancing device. (See “Configuring the Network Load Balancing Software and Driver” on page 13 for information on this file.)
12. Build your changes into the operating system:

```
# /etc/autoconfig
Automatically reconfiguring the operating system.
```
13. Turn on the Network Load Balancing Software using `chkconfig`.
14. Reboot the system to start using the reconfigured kernel.

Figure 2-2 shows `netstat -in` output with a load-balancing device as the primary Ethernet interface.

	Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs	Coll
Network Load Balancing interface (configured as primary interface)	lb0	1500	192.0.2	192.0.2.2	34220311	0	1945959	0	0
Ethernet interface	ef0	1500	192.1.2	192.1.2.3	3278730	0	801457	0	0
Devices attached to lb0	ef1	1500	192.0.2.6	192.0.2.6	1085717	0	645275	0	0
	ef2	1500	192.0.2.13	192.0.2.13	731025	0	155986	0	0
	ef3	1500	192.0.2.17	192.0.2.17	731025	0	66	0	0
	ef4	1500	192.0.2.25	192.0.2.25	730963	0	130	0	0
	lo0	32992	127	127.0.0.1	1517780	0	1517780	0	0

	Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs	Col
Network Load Balancing interface (configured as primary interface)	lb0	1500	192.0.2	192.0.2.2	34220311	0	1945959	0	
Ethernet interface	ef0	1500	192.1.2	192.1.2.3	3278730	0	801457	0	
Devices attached to lb0	ef1	1500	192.0.2.6	192.0.2.6	1085717	0	645275	0	
	ef2	1500	192.0.2.13	192.0.2.13	731025	0	155986	0	
	ef3	1500	192.0.2.17	192.0.2.17	731025	0	66	0	
	ef4	1500	192.0.2.25	192.0.2.25	730963	0	130	0	
	lo0	32992	127	127.0.0.1	1517780	0	1517780	0	

**Figure 2-2** Network Load Balancing Device as Primary Interface Example (netstat -in)

## Configuring Multiple Network Load Balancing Software Interfaces

To configure multiple network load-balancing devices, follow these steps:

1. Follow instructions for configuring and adding the load-balancing device to the system, as described in this chapter.
2. Use `systemd` to change the tunable parameter, `lb_devices`. Enter

```
systemd lb_devices numberofdevices
```

For example, this command sets the number of load-balancing devices to 2:

```
systemd lb_devices 2
```

For information on this command, see its man page, `systemd(1M)`.

3. Edit `/etc/config/nlb_options`:
  - Set `lb1name` and `lb2name` to the load-balancing device names you are using.
  - Set the shell variable `lb1devs` to a comma-separated list of Ethernet devices to be attached to the network load-balancing device lb0.

- Change the shell variable `lb_num` from the default of 1 to the number of network load-balancing devices configurable on the system.
- Save and close the file.

The following example shows entries for two network load-balancing devices:

```
lb1name=lb0
lb1devs=ef1,ef2
lb2name=lb1
lb2devs=ef3,ef4
lb_num=2
```

4. For changes in the `systemd lb_devices` parameter to take effect, build your changes into the operating system:  

```
# /etc/autoconfig
```

Automatically reconfiguring the operating system.
5. Turn on the Network Load Balancing Software using `chkconfig`.
6. Reboot the system to start using the reconfigured kernel.

## Verifying the Network Load Balancing Software Connection

To verify that the system's Network Load Balancing Software connection is working, follow these steps:

1. List all network interfaces on the system. A Network Load Balancing Software interface, such as `lb#`, must be listed.

```
% /usr/etc/netstat -in
```

If the listing does not include a Network Load Balancing Software interface, the Network Load Balancing Software may not have been installed, may not be configured, or may not be built into the operating system. Fix the problem before continuing.

2. Check that the load-balancing configuration is correct by entering

```
% /usr/etc/lbconfig interfacename
```

where `interfacename` is the name of a load-balancing interface, such as `lb0`. For example:

```
# lbconfig lb0
Interfaces configured for lb0: ef1,ef2,ef3,ef4
```

Compare the output of this command to the configuration in `/etc/config/nlb.options`. If it does not correspond, reboot and check again. If it still does not correspond, contact your service provider.

3. Use `ifconfig` to get the broadcast address:  
`% /etc/ifconfig interfacename`
4. Use the broadcast address in a `ping` command, as follows:  
`% /usr/etc/ping broadcastaddress`
5. Verify that all clients on the subnet respond.
6. You can use `lbstat -C` to further evaluate the state of the load-balancing device(s) on the system. In particular, the state for each Ethernet port attached to the load-balancing device should be `LINK_GOOD`. If a port does not show this status, check its cabling.





## Performance Tuning

Tunable parameters control how well the Network Load Balancing Software distributes outbound packets and how it balances inbound packets. This chapter describes these parameters in these sections:

- “Tuning Parameters” on page 25
- “Changing Input Load Balancing” on page 28

### Tuning Parameters

Network Load Balancing Software interface names are as follows:

```
nlb# lb0 lb1 ...
```

The Network Load Balancing Software takes a rolling average of source and destination IP addresses and port numbers: after taking the first average, subsequent averages can be tuned, as explained in “Adjusting the Average Weight” on page 29. The software then applies a hash function and collapses the result to a 32-bit number so that it can send related packets out on the same interface.

The Network Load Balancing Software has tunable parameters for adjusting the hash function multiplier, number of devices to configure, and load balancing. Reset these parameters with `systemctl`; for information, see its man page, `systemctl (1M)`.

The Network Load Balancing Software tunable parameters are as follows:

*lb\_hash\_multiplier*

Hash function multiplier, which selects the output interface. The default multiplier is 612542337. For example:

```
systemctl lb_hash_multiplier 612542337
```

*lb\_devices*

Maximum number of load-balancing devices to be configured when the system is booted. The default is 1; range is 1 to 10. This example configures the software for three active devices:

```
systune lb_devices 3
```

For the new setting to take effect, reconfigure the kernel and reboot.

See “Network Load Balancing Software and the Shell Command File /etc/init.d/network” on page 12 in Chapter 2 for information on setting the number of load-balancing devices.

*lb\_balance\_period*

Period in milliseconds used for input load balancing. This variable determines how often the input-balancing algorithm is executed. The default is 1000 ms (that is, one second); the range is 100 to 600,000 ms. See “Adjusting the Balance Period” on page 29 for instructions on adjusting this parameter.

*lb\_balance\_thresh*

Threshold for mean deviation in input byte counts above which input load balancing is triggered. The balance period is set in milliseconds. See “Adjusting the Balance Threshold Value” on page 29 for instructions on adjusting this parameter.

*lb\_average\_weight*

Weighting in units of 100 used to calculate the rolling load averages for the interfaces. See “Adjusting the Average Weight” on page 29 for instructions on adjusting this parameter

*lb\_failure\_interval*

The interval in milliseconds that Network Load Balancing Software uses to detect link failures. This determines how often the failure detection process will check the status of the underlying links on a Network Load Balancing Software device for failure. By default, the value of this parameter is 10000. The minimum is 100. The maximum is 60000. In general, this value should be greater than *lb\_balance\_period*.

*lb\_aggressive\_failure*

Use an aggressive failure detection method. This method consists of probing each interface attached to each load balancing device on each failure detection round. This parameter can be either 0 (off) or 1 (on). By default it is 0.

*lb\_fail\_thresh*

This is a threshold for the number of hosts which must be assigned to an interface for input before a link failure will be triggered by anything

other than an ENETDOWN error from the interface or an EHOSTDOWN with `IFF_UP` not set in the interface flags. The default value for this is 1.

*lb\_check\_count*

This is the number of failure detection rounds in which an interface must have an input load and input load average of 0 before the link is probed for failure. The default value is 3. Setting this to 0 will cause the link to be probed each time the load average drops to 0.

*lb\_debug*

Set the debugging level for load balancing devices.

*lb\_use\_linkdown*

Use the absence of the `IFF_LINKDOWN` flag on an interface as an indicator that the interface can be enabled after having been identified as failing. This is for compatibility with older IRIX releases where `IFF_LINKDOWN` was not implemented for all Ethernet interfaces.

## Tuning Parameters for Failure Detection and Recovery

In the event of an error, the time it takes for Network Load Balancing Software to recover depends upon network activity and the settings of the tuning parameters for Network Load Balancing Software detection and recovery. These primary tuning parameters are described in this section. For more detail information, see the `n1b(7)` man page and `/var/sysgen/mtune/if_lb` file.

The primary tuning parameters are, as follows:

*lb\_failure\_interval*

Failure detection interval in milliseconds.

*lb\_aggressive\_failure*

Use the aggressive failure detection method of probing each interface on each failure detection round.

*lb\_fail\_thresh*

This is a threshold for the number of hosts which must be assigned to an interface for input before a link failure will be triggered by anything other than an ENETDOWN error from the interface or an EHOSTDOWN with `IFF_UP` not set in the interface flags.

*lb\_\_check\_count*

The number of failure detection rounds that an interface must have an input load and input load average of 0 before the link is probed for failure.

*lb\_\_debug*

Set Network Load Balancing Software debugging to the desired level the valid settings are defined in the `bsd/sys/if_lb.h` file. This parameter has only a default setting, no maximum or minimum,

*lb\_\_use\_linkdown*

Use the absence of the IFF\_LINKDOWN flag on an interface as an indicator that the interface can be enabled (this is for compatibility with older IRIX releases where IFF\_LINKDOWN was not implemented for all Ethernet interfaces). Off by default; set to 1 to turn this on.

In addition, the failure detection time when the *lb\_aggressive\_failure* parameter is not set is affected by the following tuning parameters for input balancing:

*lb\_\_average\_weight*

The weighting in units of 100 used to calculate the rolling load averages for the interfaces. The averages are calculated from the input packet counts for each interface.

*lb\_\_balance\_thresh*

Threshold for mean deviation in input byte counts above which input load balancing is triggered. The default value is 1, the minimum is 1, and the maximum is 100000. To disable input balancing, set the *lb\_\_balance\_thresh* parameter to anything over 100.

## Changing Input Load Balancing

The Network Load Balancing Software monitors packet count on the physical interfaces and reassigns clients depending on the load. The averages are calculated from the input packet counts for each interface. You can control this process by adjusting these parameters:

- the balance period, which determines when the snapshot is taken for the rolling average
- the threshold for mean deviation in input byte counts: this parameter determines when load balancing is triggered

- the average weight used for calculating the rolling load averages for the interfaces

The rest of this section explains how to adjust these parameters.

## Adjusting the Balance Period

The balance period determines how often the input-balancing algorithm is executed. More frequent execution increases overhead proportionally. The default is 1000 ms (that is, one second).

To reset the balance period, set *lb\_balance\_period* to the desired number of milliseconds (100 to 600,000); for example:

```
systune lb_balance_period 100000
```

## Adjusting the Balance Threshold Value

The balance threshold value determines when load balancing is triggered; it is the threshold for mean deviation in input packet counts above which input load balancing is triggered. The Network Load Balancing Software calculates mean deviation, which should be less than the balance threshold.

When the mean absolute deviation, expressed as a percentage of the mean input load, exceeds this threshold, the Network Load Balancing Software attempts to balance the load by assigning a client another MAC address.

Setting the balance threshold value to a low number can result in a better input balance. However, such input balance might be impossible to achieve because the software continually moves clients from one MAC address to another.

The default balance threshold is 1%; the range is 1 to 100,000%. For example:

```
systune lb_balance_period 100
```

## Adjusting the Average Weight

The Network Load Balancing Software uses the following formula to calculate the rolling average:

$$S(n) = \frac{k}{100} \times S(n-1) + \left(1 - \frac{k}{100}\right) \times l(n)$$

$$S(n) = \frac{k}{100} \times S(n-1) + \left(1 - \frac{k}{100}\right) \times l(n)$$

where

$$0 \leq \frac{k}{100} < 1$$

$$0 \leq \frac{k}{100} < 1$$

and

$S(n)$             The approximate average of  $n$  samples.

$l(n)$             The  $n$ th sample.

$k$                 The tunable parameter, an integer that is the average weight. Default is 50; range is 0 to 99.

For example:

```
systemctl lb_average_weight 35
```

If  $k$  is 0,  $S(n)$  is always  $l(n)$ , the instantaneous load. As  $k$  increases,  $l(n)$  provides less and  $S(n-1)$  provides more of the value of  $S(n)$ . The calculation uses  $k\%$  of  $S(n-1)$  and  $100-k\%$  of  $l(n)$ .

## Troubleshooting

This chapter describes what to do when your load-balancing network connection has problems. The chapter describes the following topics:

- “Initial Remedies” on page 31
- “Connection Has Not Been Functional Since Last Boot” on page 32
- “Connection Has Been Functional in the Recent Past” on page 33
- “High Rate of Packet Loss Occurs” on page 34
- “System Cannot Communicate With Other Systems” on page 35
- “System Does Not Load Miniroot or Boot From the Network” on page 35

### Initial Remedies

When you experience difficulty with the load-balancing network connection at a particular system, you can do the following:

1. Check the physical connections at the system; consult the owner’s guides for the equipment.
2. Search or read the `/var/adm/SYSLOG` file and console window for error messages. If you find any Network Load Balancing Software driver messages, read about them in Appendix B.
3. Use `lbstat -C` to evaluate the state of the load-balancing device(s) on the system. In particular, the state for each Ethernet port attached to the load-balancing device should be `LINK_GOOD`. If a port does not show this status, check its cabling.

## Connection Has Not Been Functional Since Last Boot

If the Network Load Balancing Software connection has not been working since the last time the system was booted, or if this is an initial installation of a Network Load Balancing Software product, one or more of the following could be occurring:

- The operating system has not been rebuilt to include the driver.
- The Network Load Balancing Software interface or the aggregated Ethernets have not been configured properly.

Follow the instructions below to determine the cause of the problem:

1. Verify that the installed IRIX operating system and Network Load Balancing Software software are the correct versions by doing the following:
  - Determine the correct versions of IRIX and of the Network Load Balancing Software. The Network Load Balancing Software release notes indicate the correct IRIX and Network Load Balancing Software versions.
  - Use the *versions* command to display the installed release identifications:

```
% /usr/sbin/versions eoe.sw.base
eoe1 date Execution Only Environment 1, 6.5
```

If the version is not correct, install the correct version.

---

**Note:** The *eoe.sw.base* subsystem must be 6.5 or later for the Network Load Balancing Software to work.

---

2. View */etc/config/nlb.options*; use *lbconfig* to check for Ethernets attached to the load-balancing devices.
3. Use *netstat*, as shown below, to display the currently configured network interfaces.

```
% /usr/etc/netstat -in
```

Figure 4-1 shows example output.



	Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs	Coll
Network Load Balancing interface	lb0	1500	192.0.2	192.0.2.1	34220311	0	1945959	0	0
Ethernet interface	ef0	1500	192.1.2	192.1.2.3	3278730	0	801457	0	0
Devices attached to lb0	ef1	1500	192.0.2.6	192.0.2.6	1085717	0	645275	0	0
	ef2	1500	192.0.2.13	192.0.2.13	731025	0	155986	0	0
	ef3	1500	192.0.2.17	192.0.2.17	731025	0	66	0	0
	ef4	1500	192.0.2.25	192.0.2.25	730963	0	130	0	0
	lo0	32992	127	127.0.0.1	1517780	0	1517780	0	0

	Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs	Coll
Network Load Balancing interface	lb0	1500	192.0.2	192.0.2.1	34220311	0	1945959	0	0
Ethernet interface	ef0	1500	192.1.2	192.1.2.3	3278730	0	801457	0	0
Devices attached to lb0	ef1	1500	192.0.2.6	192.0.2.6	1085717	0	645275	0	0
	ef2	1500	192.0.2.13	192.0.2.13	731025	0	155986	0	0
	ef3	1500	192.0.2.17	192.0.2.17	731025	0	66	0	0
	ef4	1500	192.0.2.25	192.0.2.25	730963	0	130	0	0
	lo0	32992	127	127.0.0.1	1517780	0	1517780	0	0

**Figure 4-1** Displaying Available Interfaces With netstat -in

If the Network Load Balancing Software interface is not displayed, continue to the next step. If the interface is displayed, but the configuration is incorrect, follow the instructions in Chapter 2 to reconfigure it.

4. Verify the Network Load Balancing Software entries in the `/etc/config/netif.options` file. For example, check the spelling of the network interface.
5. Use `/etc/autoconfig` to rebuild the operating system to include the Network Load Balancing Software driver. Reboot the system to start using the new operating system.
6. Invoke `netstat -in` again. If the Network Load Balancing Software interface is still missing, contact your service provider.

## Connection Has Been Functional in the Recent Past

Follow these steps to resolve the problem:

1. Ensure that the system is using the operating system that was built most recently. Use `/etc/autoconfig` to rebuild the operating system, and then reboot to start using it.
2. Watch the messages on the terminal during restart to verify that each network interface is configured correctly. The messages should look similar to these examples:

```
Configuring lb0 as sys3  
Configuring ec0 as gate-sys3
```

If the load-balancing driver is not mentioned on the terminal during startup, there is a problem with the software.

3. Use `netstat` to display the currently configured network interfaces.

```
% /usr/etc/netstat -in
```

If the interface is displayed, but the configuration is incorrect, follow the instructions in Chapter 2 to reconfigure it.

The `/etc/config/netif.options` file may have an incorrect entry (for example, a misspelled network interface); verify all file contents carefully.

If the interface does not display, the software may be dysfunctional. Contact your service provider.

## High Rate of Packet Loss Occurs

If high packet loss is displayed by the `ping` command, follow these steps:

1. Confirm that the source and destination IP addresses are on the same subnet. If there was any doubt that they are, enter `ping -R`, or `traceroute` to check the route. (For information on the latter command, see its manpage, `traceroute(1M)`.)
2. If the source and destination IP addresses are attached to the same switch and `ping` still drops packets:
  - Enter `netstat -C` on the source and destination systems.
  - Enter `ping -f` on the source and destination systems to make the problem more obvious.

In the `netstat` output, inspect the packet counts and indications of input errors or output errors while `ping` is running.

If the output shows (approximately) one packet dropped per second, check for defective hardware. Make sure all cables are seated properly.

3. If the *netstat* output shows no such errors:
  - Consult the documentation for the switch and its management software.
  - Use statistics tools specific to the protocol you are using (IP, UDP, TCP/IP) to determine drops.
  - Check for defective hardware such as switch ports and problems with the cabling.

## System Cannot Communicate With Other Systems

If *ping* does not elicit a response from any system, the */etc/hosts* and */etc/config/netif.options* files may not have been set up properly. For example, the files may be configuring the Network Load Balancing Software interface with the Ethernet IP address.

Verify that the IP (inet) addresses for all network interfaces are correct. To display the currently configured IP addresses, enter

```
% /usr/etc/netstat -in
```

If the addresses are not correct, follow the instructions in Chapter 2 to reconfigure the Network Load Balancing Software.

If the problem persists, identify other problems, as described in “Verifying the Network Load Balancing Software Connection” on page 22.

## System Does Not Load Miniroot or Boot From the Network

Silicon Graphics workstations and servers are capable of loading a small-sized version of the operating system (the miniroot) and booting themselves over the network; however, they are capable of doing this only over Ethernet local area networks (they cannot boot over Network Load Balancing Software networks) that are configured as the primary network interface.

If your system is unable to load the miniroot (or boot over the network), verify that its primary network interface is an Ethernet connection by following these instructions:

1. Restart the system from the System Maintenance menu. Do not rebuild the operating system during this restart.
2. Log on and open a shell window.
3. Use these commands to display the ordering of the network interfaces:

```
% /usr/etc/netstat -i
```

```
<primary interface>
```

- <secondary interface>  
...
4. If the primary interface is an Ethernet (for example, `ef0` or `et0`), the Ethernet network connection may be dysfunctional. See *IRIX Admin: Networking and Mail* for information about Ethernet network connections.

If the primary interface is not an Ethernet, go to step 5.

5. Configure an Ethernet connection as the primary interface.
6. Reboot the system. When the system is up and running, it should be able to load the miniroot over the network and boot from it.

## Validated Ethernet Switches

Table A-1 summarizes Ethernet switches that have been specifically validated for the Network Load Balancing Software.

**Table A-1** Validated Ethernet Switches

<b>Manufacturer</b>	<b>Switch</b>
Cisco Systems, Inc.	Catalyst 5000 Switching System
	Catalyst 2900 Fast Ethernet Switching System
Alteon Networks, Inc.	ACEswitch 110
	ACEswitch 180

The Network Load Balancing Software is compatible with any Layer 2 switch.



## Error Messages

This appendix lists and explains the error messages that the Network Load Balancing Software prints to the console. Most of the messages refer to `SIOCSLSCONF`, the `ioctl` used to configure load-balancing devices.

`lbn: link failure detected on attached interface if.`

The Network Load Balancing device *n* has detected that the link *if* has failed.

`lbn: All links have failed or been disabled.`

The Network Load Balancing device *n* has detected the failure of the last configured link, or the last link has been administratively disabled.

`lbn: link recovery for attached interface if.`

The Network Load Balancing device *n* has detected that the link *if* has recovered (packets have been received on it).

`Network load balancing failure detection daemon exiting.`

The Network Load Balancing failure detection daemon is exiting, as it normally does when the system is shut down or rebooted. Occurrences of this message at times other than system shutdown or reboot indicate a problem.

`SIOCSLSCONF enable/disable: lbn not configured.`

An attempt has been made to enable or disable an interface on a load-balancing device that has not been configured.

`SIOCSLSCONF enable/disable lbn: invalid device count k.`

The number of interfaces specified when enabling or disabling an interface on load-balancing device *n* was less than 1 or greater than `MAX_INTERFACES` as specified in `/usr/include/sys/if_lb.h`. The value given was *k*.

SIOCSLSCONF enable/disable lbn: bad device list, length *k*, error *err*.

The device list passed to the load-balancing configuration ioctl SIOCSLSCONF for enabling or disabling an interface on load-balancing device *n* could not be copied from user space. The length of the list is *k*. The error number for the error that occurred during the copy is *err*.

SIOCSLSCONF enable/disable lbn: NULL device name, device *k*.

The number of entries in the list of devices to be enabled or disabled for the load-balancing device *n* was less than the number specified in the configuration structure supplied to the SIOCSLSCONF ioctl.

SIOCSLSCONF enable/disable lbn: unit *name* not found.

The network device whose name is *name* could not be enabled or disabled on load-balancing device *n* because it does not exist.

SIOCSLSCONF enable/disable lbn: unit *name* not configured.

The unit *name* could not be enabled or disabled on load-balancing device *n* because it is not attached to that device.

SIOCSLSCONF: lbn must be down for reconfiguration.

An attempt was made to reconfigure the load-balancing device *n* before the device was taken down via ifconfig.

SIOCSLSCONF: lbn: invalid device count *k*

The number of interfaces specified when load-balancing device *n* was configured was less than 1 or greater than MAX\_INTERFACES as specified in /usr/include/sys/if\_lb.h. The value given was *k*.

SIOCSLSCONF: lbn: bad device list, length *k*, error *err*

The device list passed to the load-balancing configuration ioctl SIOCSLSCONF for load-balancing device *n* could not be copied from user space. The length of the list is *k*. The error number for the error that occurred during the copy is *err*.

SIOCSLSCONF: lbn: NULL device name, device *k*

The number of entries in the list of devices to be attached to the load-balancing device *n* was less than the number specified in the configuration structure supplied to the SIOCSLSCONF ioctl.



---

SIOCSLSCONF: *lbn*: unit *name* not found.

The network device whose name is *name* could not be attached to load-balancing device *n* because it does not exist.

SIOCSLSCONF: *lbn*: unit *name* has no primary address.

Every network device must have a primary IP address, which must be assigned before the load-balancing device is configured.

*n* indicates the load-balancing device being configured when the error was detected. The offending device's name is *name*.

SIOCSLSCONF: *lbn*: unit *name* has an invalid subnet mask *x*.

All network devices to be attached to a load-balancing device must have the subnet mask 0xffffffff, which must be set before the load-balancing device is configured.

*n* indicates the load-balancing device being configured when the error was detected. The offending device's name is *name*.

SIOCSLSCONF: *lbn*: unit *name* error *err* setting flags.

This error was encountered when attempting to set the device flags for a device being attached to a load-balancing device.

*n* indicates the load-balancing device being configured when the error was detected. The offending device's name is *name*.

SIOCSLSCONF: *lbn*: the units are not all of the same type.

All network devices attached to a load-balancing device must be of the same type: 10-Base-T, 100-Base-T, or gigabit Ethernet.

*n* indicates the load-balancing device being configured when the error was detected.

SIOCSLSCONF: unable to start *lbn*, error *err*.

Error *err* was encountered when attempting to start load-balancing device *n*.

Unable to allocate load balancing device data.

The kernel had insufficient memory available to allocate the data structures required by the load-balancing devices.

