

50'S STRATOCASTER 0131002

SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION					
5 ○ ○ ○ ○ ○	4 ○ ○ ○ ○	3 ○ ○ ○	2 ○ ○ ○	1 ○ ○	← 5 WAY SWITCH POSITION
■	■	○	○	○	← NECK PICKUP
○	■	■	■	○	← MIDDLE PICKUP
○	○	○	■	■	← BRIDGE PICKUP
					← PICKUP IS ON
					← PICKUP IS OFF

