

DYNA-QUIK MODEL 675 TUBE CHART

TUBE TYPE	HEATER	CARD No.	TEST POS.	SENSITIVITY SETTING		
				Good-Bad	True G _m	Stand. G _m
6662	6	1	1	81	75	3600
6663	6	13	1 2	57 57		
6669	6	31		74	69	3700
6677	6	19		35	32R	11000
6678	6	15	1 2	71 53	41R 28R	5200 8500
6679	12	2	1 2	69 69	44R 44R	5500 5500
6680	12	2	1 2	69 53	53	2200
6681	12	53	2 1	69 90	53 58	2200 1600
6829	12	2	1 2	55 55	58	1600
6887	6	13	1 2	57 57		
6919	6	13	1 2	61 61		
6973	6	41		62	26R	4800
7025	12	53	1 2	90 90	58 58	1600 1600
7054	12	11		44	39R	11000
7055	12	13	1 2	57 57		
7056	12	1		62	36R	6200
7057	12	2	1 2	48 48	17R 17R	6800 6800
7058	12	53	1 2	90 90	58 58	1600 1600
7059	12	15	1 2	71 53	41R 28R	5200 8500
7060	12	16	1 2	54 60	19R 60	7000 4900
7061	12	41		65	63	4100
7167	12	1		55	30R	8000
7189-A	6	61		33	25R	11300
7247	12	53	1 2	69 90	52 58	2200 1600
7258	12	45	1 2	62 62	38R	6200
7408	6	14	1	74	74	4100
7543	6	1		80	51R	4500
7581	6	14		63	36R	6000
7687	6	15	1 2	73 65		
8016	1	10	1	51		
9001	6	1	1	90		
9003	6	1	1	99		
ARP17	6	14	1	90	71	2500
ARP32	6	14	1	74	74	4100
ARP33	6	14	1	74	74	4100
AU13	5	3	1	21		
AZ32	4	3	1	21		
B36	12	4	1 2	92 92	76	2600
B65	6	4	1 2	92 92	76	2600
B152	12	2	1 2	69 69	44R 44R	5500 5500
B309	12	2	1 2	69 69	44R 44R	5500 5500
B329	12	2	1 2	69 69	53 53	2200 2200
B339	12	53	1 2	90 90	58	1600
B719	6	2	1	65	40R	5900
BPM04	6	31		74	69	3700
CV133	6	21	1	70	53	2200
CV283	6	13	1 2	57 90		
CV452	6	35	1 2 3	57 90 62	55	1300
CV453	6	1	1	91		
CV454	6	1	1	74	76	4400
CV455	12	2	1 2	69 69	44R 44R	5500 5500
CV491	12	2	1 2	69 69	53	2200
CV492	12	53	1	90	58	1600
CV493	6	34	1 2	15 15		
CV511	6	14	1	74	74	4100
CV538	12	26	1	100		
CV544	12	25	1	81	56	2000
CV547	12	27	1 2	98 90	53R	1175
CV551	25	14	1	52	21R	7100
CV552	25	14	1	42	21R	8000
CV553	25	14	1	42	21R	8000
CV561	35	14	1	54	21R	5800
CV562	35	14	1	54	21R	5800
CV567	35	28	1	9		
CV568	35	28	1	9		
CV571	50	14	1	42	21R	8000
CV572	6	3	1 2	16 16		
CV573	6	3	1 2	16 16		
CV574	6	3	1 2	16 16		
CV575	5	3	1 2	13 13		
CV581	6	14	1	95	71	2000
CV582	6	14	1	95	71	2000
CV583	6	14	1	95	71	2000
CV586	6	14	1	63	36R	6000
CV590	6	25	1	81	56	2000
CV591	6	25	1	79	51	1650
CV592	6	25	1	79	51	1650
CV593	5	3	1 2	12 12		
CV594	6	25	1	75	79	4900
CV595	6	25	1	75	79	4900
CV660	6	25	1	56	50R	9000
CV661	6	25	1	70	42R	5000
CV665	6	1	1	99		
CV694	12	25	1	72	70	4000
CV697	12	25	1	79	51	1650
CV698	12	25	1	79	51	1650
CV700	12	27	1 2	84 87	58	1900
CV717	5	3	1 2	23 23		
CV728	1	54	1	74		
CV729	5	3	1 2	12 12		
CV731	6	14	1	90	71	2500
CV732	6	8	1	9		
CV747	6	25	1	56	50R	9000
CV753	2	1		92		
CV755	1	54	1	75		
CV756	1	54	1	75		
CV760	1	54	1	66		
CV772	1	54	1	63		
CV773	1	54	1	63		
CV782	1	55	1	70		
CV783	1	55	1	64		
CV784	1	55	1	68		
CV785	1	55	1	67		
CV807	3	55	1	63		
CV818	3	55	1	63		
CV819	3	54	1	65		
CV820	3	55	1	65		
CV841	5	3	1 2	13 13		
CV842	5	3	1 2	29 29		
CV846	6	25	1	56	50R	9000
CV848	6	1	1	72	52R	5000
CV849	6	25	1	56	50R	9000
CV850	6	1	1	60	25R	5100
CV852	6	21	1	70	53	2200
CV858	6	12	1	57	28R	5300
CV865	6	25	1	68	27R	4250

DYNA-QUIK MODEL 675 TUBE CHART

TUBE TYPE	HEATER	CARD No.	TEST POS.	SENSITIVITY SETTING		
				Good-Bad	True Gm	Stand. Gm
DP61	6	1		60	25R	5100
DY30	1	10		51		
DY80	1	9	1	87		
DY86	1	9		35		
DY87	1	9	1	35		
E80CC	12	2	1	77		
			2	77		
E90CC	6	12	1	50		
			2	50		
E91AA	6	13	1	57		
			2	57		
EEA91	6	13	1	57		
			2	57		
EABC80	6	37	1	92	54	1200
			2	58		
			3	58		
EB91	6	13	1	57		
			2	57		
EBC90	6	35	1	90	55	1300
			2	62		
			3	62		
EBC91	6	35	1	90	57	1600
			2	65		
			3	65		
EC90	6	21		70	53	2200
EC92	6	21		66	35R	5500
EC95	6		1	60	55	
ECC35	6	27	1	98	53R	1175
ECC81	12	2	1	69	44R	5500
			2	69	44R	5500
ECC82	12	2	1	69	53	2200
			2	69	53	2200
ECC83	12	53	1	90	58	1600
			2	90	58	1600
ECC85	6	2	1	65	40R	5900
			2	65	40R	5900
ECC88	6	2	1	25		
			2	25		
ECC91	6	12	1	57	28R	5300
			2	57	28R	5300
ECC189	6	2	1	32		
			2	32		
ECC801S	12	2	1	69	44R	5500
			2	69	44R	5500
ECC802S	12	2	1	69	53	2200
			2	69	53	2200
ECC960	6	12	1	50		
			2	50		
ECF80	6	15	1	63	39R	6200
			2	53	17R	5000
ECF82	6	15	1	71	41R	5200
			2	53	28R	8500
ED2	6	13	1	57		
			2	57		
EF22	6	56	1	63		
EF93	6	1		74	76	4400
EF94	6	1		72	52R	5200
EF95	6	1		60	25	5100
EF96	6	1		72	52R	5000
EH90	6	1		95	45	1100
EK90	6	1		91		
EL34	6	14		53	51R	11000
EL37	6	14		63	36R	6000
EL84	6	61		52	46R	11300
EL85	6	61	1	72		
EL86	6	61		20	16R	10000
EL90	6	31		74	69	3700
EL95	6	31	1	84		
EY86	1	9	1	35		
EZ35	6	3	1	16		
			2	16		
EZ90	6	34	1	15		
			2	15		
GZ30	5	3		15		
GZ32	5	3	1	12		
			2	12		
GZ34	5	3	1	10		
			2	10		

TUBE TYPE	HEATER	CARD No.	TEST POS.	SENSITIVITY SETTING		
				Good-Bad	True Gm	Stand. Gm
HABC80	19	37	1	92	54	1200
			2	58		
HBC90	12	35	1	90	55	1200
HBC91	12	35	1	90	57	1600
			2	65		
			3	65		
HCC85	17	2	1	62		
			2	62		
HD14	1	54	1	70		
HF93	12	1	1	74	76	4400
HF94	12	1	1	72	52R	5200
HK90	12	1	1	91		
HL90	19	31		74	69	3700
HL92	50	32		45	20R	7500
HMO4	6	1		91		
HY90	35	33		9		
KT32	25	14		42	21R	8000
KT63	6	14		90	71	2500
KT66	6	14		63	36R	6000
KT88	6	14		52		
L63	6	14	1	89	73	2600
L77	6	21		70	53	2200
LZ319	9	15	1	63	39R	6200
			2	53	17R	5000
M8081	6	12	1	57	28R	5300
M8100	6	1	1	60	25R	5100
N14	1	54	1	64		
N17	3	55	1	65		
N18	3	55	1	63		
N19	3	55	1	63		
N77	6	13	1	57		
			2	57		
N709	6	61	1	52	46R	11300
NR78	6	14	1	95	71	2000
NR78-A	6	14	1	89	73	2600
NR85	6	14	1	90	71	2500
NR95	25	14	1	42	21R	8000
NU20	5	3	1	21		
			2	21		
OBC3	12	27	1	98	53R	1175
			2	90		
OSW2190	6	25	1	56	50R	9000
OSW2192	6	25	1	34	31R	11000
OSW2600	6	25	1	56	50R	9000
OSW2601	6	25	1	34	31R	11000
OSW3105	6	27	1	98	53R	1175
OSW3106	6	14	1	74	74	4100
OSW3108	6	14	1	63	36R	6000
OSW3111	6	25	1	81	56	2000
OSW3112	6	14	1	89	73	2600
PABC80	9	37	1	92	54	1200
			2	58		
			3	58		
PCC85	9	2	1	65	40R	5900
			2	65	40R	5900
PCC88	7	2	1	25		
			2	25		
PCF80	9	15	1	63	39R	6200
			2	50	17R	5000
PCF82	9	15	1	71	41R	5200
			2	53	28R	8500
PL84	15	61	1	20	16R	10000
PM04	6	1	1	74	76	4400
PM05	6	37	1	92	54	1200
			2	58		
			3	58		
QA2404	6	13	1	57		
			2	57		
QA2406	12	2	1	69	44R	5500
			2	69	44R	5500
QA2407	6	34	1	15		
			2	15		
QA2408	6	4	1	92	76	2600
			2	92	76	2600
R52	5	3	1	15		
			2	15		
SN7	1	10	1	51		
T2M05	6	12	1	57	28R	5300

* or Δ Cards available in Accessory Package ASM-10

□ Cards available in Accessory package ASM-54

R Where R appears read Red Scale

DYNA-QUIK MODEL 675 TUBE CHART

TUBE TYPE	HEATER	CARD NO.	TEST POS.	SENSITIVITY SETTING		
				Good-Bad	True Gm	Stand. Gm
TS51	6	1	1	60	25R	5100
TS52	6	12	1	57	28R	5300
U50	5	3	1	21		
			2	21		
U52	5	3	1	13		
			2	13		
U54	5	3	1	10		
			2	10		
U78	6	34	1	15		
			2	15		
U147	6	3	1	16		
			2	16		
UAA91	19	13	1	57		
			2	57		
UABC80	30	37	1	92	54	1200
			2	58		
			3	58		
UCC85	25	2	1	65	40R	5900
			2	65	40R	5900
UCF80	25	15	1	63	39R	6200
			2	53	17R	5000
UL84	50	61	1	52	46R	11300
UU12	6		2	10		
			3	10		
V2M70	6	34	1	15		
			2	15		
VT52	6	14	1	86	67	2300
VT65	6	14	1	95	71	2000
VT66	6	14	1	90	71	2500
VT74	5	3	1	15		
			2	15		
VT94	6	14	1	89	73	2600

TUBE TYPE	HEATER	CARD NO.	TEST POS.	SENSITIVITY SETTING		
				Good-Bad	True Gm	Stand. Gm
VT97	5	3	1	29		
			2	29		
VT102	6	14	1	86	67	2300
VT103	6	27	1	98	53R	1175
VT104	12	27	1	98	53R	1175
			2	90		
			3	90		
VT107	6	14	1	74	74	4100
VT112	6	25	1	56	50R	9000
VT114	5	3	1	14		
			2	14		
VT115	6	14	1	63	36R	6000
VT116	6	25	1	79	51	1650
VT117	6	25	1	81	56	2000
VT124	1	54	1	75		
VT125	1	54	1	64		
VT126	6	3	1	16		
			2	16		
W17	1	55	1	67		
W149	6	56	1	86	59	1750
W727	6	1	1	74	76	4400
X107	19	1	1	91		
X155	6	2	1	54	33R	8000
			2	54	33R	8000
X727	6	1	1	91		
XCC189	4	2	1	32		
			2	32		
XL84	8	61	1	52		
XXD	12	57	1	73	54	2100
			2	73	54	2100
XXL	6	56	1	70	56	2600
Z14	1	54	1	75		
ZD17	1	55	1	64		

ACCESSORY PACKAGES OF CARDS ARE AVAILABLE AS FOLLOWS

ASM-10—Consists of 13 pre-punched cards to test

Hybrid Auto Radio Tubes\$1.95

12AC6	12AL8	12DV8	12EK6	12FM6
12AD6	12BL6	12DY8	12EL6	12FT6
12AE6	12CN5	12DZ6	12EM6	12GA6
12AE7	12CX6	12EA6	12EZ6	12J8
12AF6	12DL8	12EC8	12F8	12K5
12AG6	12DS7	12EG6	12FK6	12U7
12AJ6				

ASM-54—Consists of 7 pre-punched cards to test

Hybrid Auto Radio Tubes\$1.50

12DE8	12DV7	12FR8
12DK7	12DW8	12FX8
12DU7		

ASM-21—Consists of 12 blank cards for future use\$1.75

K4XL's **BAMA**

This manual is provided **FREE OF CHARGE** from the "BoatAnchor Manual Archive" as a service to the Boatanchor community.

It was uploaded by someone who wanted to help you repair and maintain your equipment.

If you paid anyone other than BAMA for this manual, you paid someone who is making a profit from the free labor of others without asking their permission.

You may pass on copies of this manual to anyone who needs it. But do it without charge.

Thousands of files are available without charge from BAMA. Visit us at <http://bama.sbc.edu>