

*Heathkit*  
ANTENNA  
IMPEDANCE METER




THE HEATH COMPANY  
BENTON HARBOR, MICH.

MODEL AM-1



PHONES






ANTENNA IMPEDANCE METER SCHEMATIC


# ASSEMBLY AND OPERATION OF THE HEATHKIT ANTENNA IMPEDANCE METER

MODEL AM-1



## SPECIFICATIONS

Frequency Range.....	0-150 megacycles
Impedance Range.....	0-600 ohms
Null Indicator.....	100 $\mu$ ampere meter
Dimensions.....	2 1/2" x 3" x 7"
Net Weight.....	1 lb.
Shipping Weight.....	3 lbs.



ANTENNA IMPEDANCE METER SCHEMATIC



## ANTENNA RESONANCE AND RESISTANCE

It may seem strange to consider finding antenna resonance by any other means than the grid dip method when a grid dip is already on hand to use with the Antenna Impedance Meter. However, there are cases where a reading by the grid dip method is difficult to obtain, especially when the antenna is of low Q, or when the element diameter is large. In other situations it may be physically impractical to reach the point at the antenna required for accurate measurement. It is also often impossible to obtain sufficient coupling to a long wire or low frequency antenna, even if it were accessible for measurement. The AM-1 may be employed directly at the antenna or at a convenient point removed from the antenna. Resistance and resonance measurements may be made in one operation because the antenna impedance is resistive at resonance. Occasional reference to the standard antenna formula will materially aid in correlating readings. From the following data it will become apparent that the AM-1 may be used in several different ways, either separately or in other combinations to achieve the same paramount end result of getting the antenna tuned up and the transmission line matched for optimum results. The procedure to follow is a matter of convenience and depends upon the problems in each individual case.

### HALF WAVE DIPOLE

If the center of the antenna is within reach when it is in its normal position, the AM-1 may be connected directly at the center, as shown in Figure 6. The center of the antenna must be open in order to connect it to the instrument. The leads at this point should be absolutely no longer than is necessary to make the connection. The binding post can be screwed down tight on the connecting leads and will be sufficient to hold the instrument. In any event, do not support the instrument by holding the case by hand because this will produce serious unbalance. The frequency range to employ at the generator may be ascertained by first approximating the antenna frequency according to the standard formula:

$$F_{mc} = \frac{492 \times .95}{\text{Length in feet}}$$

Set the AM-1 dial near 50 ohms and vary the generator frequency until the best null is indicated. Then rotate the impedance dial until the complete null is realized. The generator frequency may have to be slightly readjusted before the complete null is found. The antenna resistance will then be indicated by the dial reading of the AM-1 and the antenna resonant frequency will be that at which the generator is now set. Resistance readings will vary between 10 and 100 ohms being




Figure 6




Figure 7



mainly dependent upon exact height above ground and upon nearby elements or other objects. Tests on half-wave antennas at various heights above ground have indicated close adherence to the standard curves of resistance versus height when the measurements were made under similar conditions. Do not expect indoor antennas to behave in the normal manner as their characteristics vary to a surprising extent. At frequencies above 50 mc, the readings are apt to be effected by the presence of the instrument at the center of the antenna and/or the presence of the person making the measurements. Readings will then have to be obtained at a point removed from the immediate proximity of the antenna. This will also be necessary when an antenna is inaccessible for direct readings. It was demonstrated earlier that a half wave line repeats its load as seen from the sending end. Thus a half wave line or any multiple thereof may be connected to the center of the antenna and the measurements may be made at the lower end of the line. See Figure 7. These readings will then be a duplicate of those obtainable directly at the antenna, regardless of line impedance as long as the line is an exact electrical half wave of the antenna frequency. Now the question may arise as to how the correct half wave length may be determined in view of the fact that the exact antenna resonant frequency is one of the unknowns to be measured. Although measurements of existing antennas may be desired, it is recommended that the antenna system be tuned or adjusted to a prescribed frequency in order to assure peak performance. This will generally be the eventual step anyway and it will simplify remote readings because the half wave line may be first cut to the specified frequency using the antenna impedance meter method, described earlier, following which the antenna may be trimmed to the correct frequency according to the readings obtained with the instrument at the lower end of the line. The best procedure for existing antennas is to calculate the antenna frequency approximately by the standard formula and then use this as the basis for ascertaining the frequency for the half wave line. The alternative method is to use a line of impedance near that of expected value of the antenna resistance. The mismatch will probably not be too great and the error will be slight. If the antenna is within reach and if a grid dip measurement is possible, the frequency may be found accordingly. It is obvious that this will apply mainly when the resistance only is to be read or when the resonant frequency is to be confirmed. Several precautions must be exercised when making remote measurements. The half wave line should run at a right angle away from the antenna for a distance of at least a quarter wave length to minimize unwanted coupling to the antenna. If open wire or twin lead is utilized, twist the line about one turn every two feet. This will tend to cancel out line unbalances to ground which may effect the reading, particularly since the AM-1 is in itself an unbalanced device. The case of the instrument should always be insulated from ground and it should be placed so as to minimize capacitance between the case and nearby grounded objects. Line unbalance may be checked by reversing the connections at the output terminals. Little change, if any, should be noted in the readings. With high frequency antennas it is usually best to employ a line several half waves long to reduce the effect of personal body presence. If the AM-1 meter should read above zero when the antenna or line is connected to the instrument, and when no generator signal has yet been applied, most likely RF energy is being picked up from some nearby broadcast station or other high power source. This has been experienced with several cases involving 3.5 mc antennas. Often just reversing the line is sufficient to drop the reading down to zero. If this does not rectify the situation, about the only other remedy is to wait for the interference to cease. By using headphones in the phone jack, the interfering signal may be identified.

#### FOLDED DIPOLES

Measurements may be made in the same manner as with the normal dipole. See Figure 8. The AM-1 or the half wave feed line should be connected to the normally open section at the center. If any frequency check is to be made by the grid dip method, the open center must first be shorted. Resistance readings of folded dipoles will generally run between 150 and 350 ohms. In some cases it may be possible to obtain a second null in the 500 ohm region at a slightly different frequency. This is due to the following. Refer to Figure 9. The overall length A determines the natural period of the antenna. However, each half of the antenna, sections B and C, are lines quarter wave long at a frequency which may differ slightly from the overall frequency depending upon the height above ground or upon the presence of other elements. With open wire or tubing this is usually not pronounced and is of little consequence but with a folded dipole made of twin lead, this effect will be quite apparent with a wider frequency difference due to the ve-



locity of propagation factor of the twin lead. The frequency of the quarter wave section's being about 86% lower from that of the overall natural period. The net result of this situation narrows the frequency versus impedance response and the twin lead folded dipole then no longer embodies as broad a characteristic as that of the open wire type. The correct antenna impedance meter reading will be the one found at the higher frequency. The usual suggested method of altering this situation is that of inserting a fixed capacitor in series with each shorted end. The capa-




Figure 8




Figure 9




Figure 10




Figure 11

capitance is dependent upon frequency, being approximately  $7 \mu\mu\text{f}$  per meter. An alternative method which is more practical is to connect another short across each section at approximately 86% of the distance from the center as shown in Figure 10. The quarter wave sections will then be each nearly tuned to the overall natural period of the antenna and the impedance characteristic will be broadened. A corrected twin lead folded dipole may be easily and accurately set up through the employment of the AM-1. First cut a length of twin lead to an electrical length of a half wave at the desired frequency, using the instrument as described earlier. Then place permanent shorts across each end of the line and at the exact center open one side of the line for the feed point. Now add equal lengths of wire at each end of the twin lead so that the total length of the antenna will be slightly longer than calculated by formula. See Figure 11. Then using the Antenna Impedance Meter, connect it directly or remotely at the center, trim the end wires equally until resonance is indicated at the desired frequency. If remote measurements are to be made, and if the half wave line to be used is made of the same type twin lead, its length will naturally be the same as that of the section installed in the antenna. The properties of this antenna will be approximately the same as those of the ordinary dipole.

### HARMONIC ANTENNAS

Antennas made up of any multiple lengths of half waves may be measured at the desired operating frequency by connecting the AM-1 either directly or remotely at any high current point. As an example, Figure 12 indicates the correct points when using a three half wave antenna. The resistance readings will be only for that at the particular point of measurement. Resonance for this antenna when measured at  $X_1$  will be that of the third harmonic, while readings taken at the center point  $X$  will be those of the fundamental or any odd harmonic. Readings of other harmonics may be made at points determined by the theoretical location of current loops.




Figure 12



Figure 13






Figure 14

## QUARTER WAVE VERTICAL AND GROUND-PLANE ANTENNAS

Connect the AM-1 or half wave line at the normal feed point between the base of the antenna and ground or radial as the situation may require. See Figure 13. The resistance reading will be approximately 35 ohms. Since the resistance at the feed point of the ground-plane antenna may be raised by dropping the radials to form a larger than  $90^{\circ}$  angle with the vertical element, the AM-1 is a handy device for determining the correct angle for the desired resistance in any specific case. See Figure 14. The limit obtainable is about 70 ohms at which point the radials will be folded all the way down so they too are vertical and the system then resolves into a form of coaxial antenna. Resonance of the vertical antenna may be adjusted by varying the length of the vertical portion and that of the radials if involved.

## MOBILE ANTENNAS

Quarter wave mobile antennas may be measured for resonance and resistance in the same manner as employed with the vertical antennas. See Figure 15. The average antenna of this type will have about 45 ohms resistance providing a sufficiently close match for a 50 ohm line. Base or center loaded antennas may be likewise checked. Resistance readings will be in the 20 to 35



ohm regions. Refer to Figure 16. By correctly proportioning the antenna length in the ratios of L and C, the system may be adjusted so the feed point will have a resistance value to match either a 50 or 70 ohm line. The correct adjustments may be determined according to readings found with the AM-1.

## PARASITIC BEAMS

Connect the AM-1 or half wave line at the center of the driven element as with any half wave antenna. Resistance readings will usually lie between 10 and 100 ohms, being dependent upon the exact spacing and tuning of the other elements. Resonance will also be dependent to some extent upon these factors which will make it difficult to calculate exactly the length of the half wave if needed for remote measurements. For this situation, the antenna system may be tuned up to a prescribed frequency with the line cut accordingly as previously suggested. However, in most cases the center of the driven element will be accessible, so the instrument may be used directly. Occasionally one or two slightly different frequencies may be indicated by the AM-1. This is due to reflections from other elements and must be analyzed in each individual case. With the beam correctly tuned, only one frequency will be indicated by a complete null at the true resonant frequency. As already stated, partial nulls indicate reactive impedance which will be the incorrect point to consider. It has been found generally good practice to resonate the driven element while the reflector is set at a length about 5% longer than this element and the director set about 5% shorter. The beam adjustment may then be left set since only little improvement will usually be gained over this arrangement by retuning the parasitic elements



through the customary lengthy process of checking against field strength readings. But, if finite adjustments of the other elements is desired, it is suggested that the AM-1 be employed as a means of initially tuning the driven element. The parasitic elements may then be tuned in their usual manner with occasional checks being made for antenna resonance. This latter step may be made with the AM-1 used as a S. W. R. meter as will be subsequently explained.

#### ADJUSTING Q BARS

Q bars, as quarter wave transformers, often used as a matching device between an antenna and a transmission line, may be adjusted by connecting the AM-1 at the line end of the bars, with the other end being connected to the antenna. The spacing between the bars should then be adjusted to obtain the necessary impedance. They must first be cut to the correct length and the antenna must be resonant at the frequency to be used.

#### STANDING WAVE RATIO

If the meter indicates a complete null when the AM-1 is inserted into the transmission line, the indicated S. W. R. will be unity or 1:1. Ratios higher than 1:1 may be determined if the line is a multiple of a half wave long at the resonant frequency involved and if the antenna is resonant. Just rotate the AM-1 dial while slightly adjusting the generator frequency if required, until the null is found indicating the resistance of the termination. The S. W. R. may then be determined by:

$$S. W. R. = \frac{Z \text{ load}}{Z \text{ line}}$$

The instrument itself may be calibrated for various ratios but the readings will be inaccurate unless the above conditions prevail. Lines of other lengths will reflect an impedance different than that found at the termination and this impedance will be reactive particularly if the antenna is not resonant. The same difficulty of obtaining an accurate reading of S. W. R. other than 1:1 may be found with many current types of S. W. R. meters. As with other measurements, the ideal procedure is to tune up an antenna to a prescribed frequency while matching the line. This may be readily done with the AM-1 connected at the sending end of the line. In order to avoid confusing nulls, due to line resonances, it is suggested that the length of the line be held shorter than one wave length. Set the instrument dial at the line impedance and vary the generator frequency near that calculated for the antenna, until a null is observed. If this occurs at a point other than at the desired frequency, adjust the antenna until resonance is obtained at the correct frequency as indicated by the AM-1 null. If the null is incomplete and a variable matching device is being used, it should be adjusted until a complete null is realized at the resonant frequency. When a matching system such as the T match is employed, an antenna will often have to be resonated with each subsequent change in the setting of the T as the antenna will be affected by these changes. If no variable matching arrangement is used, and if the line is otherwise correctly terminated at the resonant antenna, the meter will indicate a complete null and the S. W. R. will be unity. Stress is again placed on the fact that the unity ratio cannot be obtained unless the line is not only terminated by an impedance equal to its own impedance, but also that this impedance must be resistive which in turn is not possible unless the antenna is resonant at the frequency involved. When the complete null is realized indicating a 1:1 ratio, the length of the transmission line should be altered by 1/8 or 1/4 wave length to verify the reading. If the S. W. R. has been correctly adjusted to unity, no change should be noted in the meter null.

#### RECEIVER INPUT IMPEDANCE

Connect the AM-1 to receiver input terminals and tune receiver to the frequency at which the impedance is to be determined. Set the generator at the same frequency and rotate the impedance dial until the complete null is found. Retrim generator frequency if necessary. As with antennas, the input circuit must resonate at the frequency employed in order to read the resistive component. If the input circuit is tightly coupled as it is on many sets, two impedance readings at slightly different frequencies will be noted. One reading will be low between 10 and 20 ohms and the other reading will be anywhere from 50 to 500 ohms. The reason for this is that the reactance of the coupling loop between the generator and the input side of the AM-1 reflects upon the tuned input circuit of the receiver, the very low impedance reading being evidenced at this point. Although the loop reactance may be tuned out, moderate accuracy may be had by relying upon the higher reading.



## PHONE MONITOR

By adding a short length, 6 to 12 inches, of wire to either the "hot" input or output terminals of the AM-1, and plugging a pair of earphones into the phone jack, the AM-1 may be used to monitor radio telephone transmissions, thus giving the operator an indication of the quality of his modulation.

## FIELD STRENGTH METER

By placing a circuit tuned to the frequency of the transmitter across the output terminals of the AM-1 and adding a suitable length of antenna, the instrument may be used to a limited extent as a field strength meter. Although it has no built-in amplification, the high sensitivity of the AM-1 will allow it to be used as a relative field strength meter where the RF field strength is fairly high. With approximately a 100  $\mu\mu\text{f}$  variable condenser and a suitable plug-in socket, the normal grid dip meter coils may be used as the parallel tuned circuit for the field strength meter. A unique cause of TVI has been found to be rectification and re-radiation from natural objects such as furnaces, drain pipe spouting, etc. The AM-1 used as a field strength meter either with or without the tuned circuit, may be used to locate radiation from such objects. Grounding or bonding of the joints in these objects may then eliminate the source of TVI.

## IN CASE OF DIFFICULTY

Due to the extreme simplicity of this kit, there is very little chance of trouble. However, a few possible indications of improper operation and their causes are outlined below.

### INDICATION

### CAUSE

Meter reads backwards.

1. Meter mounting on panel reversed.
2. Crystal diode connected backwards in circuit.

Low sensitivity.

1. 200  $\Omega$  resistor to ground open.

Meter will not indicate a null when properly operated.

1. 200  $\Omega$  resistor from potentiometer open.

Meter will not indicate under any conditions.

1. RF source in-operative.
2. Crystal diode defective.
3. Phone jack shorting blade not making contact.
4. Phone jack wired incorrectly.
5. Open 10 K $\Omega$  resistor.

Portions of this manual have been reprinted with permission from September, 1950 C. Q.

## REPLACEMENTS

Material supplied with Heathkits has been carefully selected to meet design requirements and ordinarily will fulfill its function without difficulty. Occasionally improper instrument operation can be traced to a faulty component. Should inspection reveal the necessity for replacement, write to the Heath Company and supply all of the following information:

- A. Thoroughly identify the part in question by using the part number and description found in the manual parts list.
- B. Identify the type and model number of kit in which it is used.
- C. Mention the order number and date of purchase.
- D. Describe the nature of defect or reason for requesting replacement.

The Heath Company will promptly supply the necessary replacement. Please do not return the original component until specifically requested to do so. Do not dismantle the component in question as this will void the guarantee. This replacement policy does not cover the free replacement of parts that may have been broken or damaged through carelessness on the part of the kit builder.



## SERVICE

In event continued operational difficulties of the completed instrument are experienced, the Heath Company is willing to offer its full cooperation to assist you in obtaining the specified performance level in your instrument. The facilities of our Service Department are at your disposal, and your instrument may be returned for inspection and repair for a service charge of \$3.00, plus the price of any additional parts or material that may be required.

The services of our Technical Consultation Department are also available to you, without charge. Our technical consultants are thoroughly familiar with every instrument and can usually localize the trouble from a suitable description of the difficulty encountered.

It is necessary that you provide full and complete information concerning your problem when writing to our Technical Consultation Department for assistance, or when returning your instrument for Factory Repair Service. For instance, clearly identify the kit involved, giving the purchase date and, if possible, the invoice number; describe in detail the difficulty that you have encountered, state what you have attempted to do to rectify the trouble, what results have been achieved, and include any information or clues that you feel could possibly be of value to the consultant who handles your problem.

Local Service by Authorized Heathkit Dealers is also available and often will be your fastest, most efficient method of obtaining service for your Heathkits. Although you may find charges for local service somewhat higher than those listed in Heathkit manuals (for factory service), the amount of increase is usually offset by the transportation charges you would pay if you elected to return your kit to the Heath Company.

Heathkit dealers will honor the regular 90 day Heathkit Parts Warranty on all kits, whether purchased through a dealer or directly from Heath Company. It will be necessary that you verify the purchase date of your kit by presenting your copy of the Heath Company invoice to the authorized dealer involved.

Under the conditions specified in the Warranty, replacement parts are supplied without charge; however, if your local dealer assists you in locating a defective part (or parts) in your Heathkit, or installs a replacement part for you, he may charge you for this service.

Heathkits purchased locally and returned to Heath Company for service must be accompanied by your copy of the dated sales receipt from your authorized Heathkit dealer in order to be eligible for parts replacement under the terms of the Warranty.

THESE SERVICE POLICIES APPLY ONLY TO COMPLETED INSTRUMENTS CONSTRUCTED IN ACCORDANCE WITH THE INSTRUCTIONS AS STATED IN THE MANUAL. Instruments that are not entirely completed or instruments that are modified in design will not be accepted for repair. Instruments showing evidence of acid core solder or paste fluxes will be returned NOT repaired.

For information regarding modifications of Heathkits for special applications, it is suggested that you refer to any one or more of the many publications that are available on all phases of electronics. They can be obtained at or through your local library, as well as at most electronic outlet stores. Although the Heath Company sincerely welcomes all comments and suggestions, it would be impossible to design, test, evaluate and assume responsibility for proposed circuit changes for specific purposes. Therefore, such modifications must be made at the discretion of the kit builder, according to information which will be much more readily available from some local source.

## PARTS LIST

<u>PART No.</u>	<u>PARTS Per Kit</u>	<u>DESCRIPTION</u>	<u>PART No.</u>	<u>PARTS Per Kit</u>	<u>DESCRIPTION</u>
<b>Resistors-Condensers-Rectifiers</b>			<b>Hardware</b>		
1-20	1	10 K $\Omega$ resistor	250-8	2	#6 x 3/8 sheet metal screw
2-83	2	200 $\Omega$ resistor 1%	250-10	6	6-32 x 1/2 screw
10-34	1	600 $\Omega$ potentiometer	250-16	1	8-32 x 3/16 set screw
21-27	2	.005 $\mu$ fd ceramic condenser	252-3	10	6-32 nut
56-4	1	Crystal rectifier	252-7	2	Control nut
<b>Meters-Knobs-Insulators</b>			253-10	2	Control nickel washer
75-6	2	Polystyrene insulator	254-1	6	#6 lockwasher
75-14	1	Polystyrene mounting plate	255-2	2	#6 x 3/16 spacer
100-M16B	2	Binding post cap, black	259-1	5	#6 solder lug
100-M16R	2	Binding post cap, red	259-6	2	Solder lug, small
100-M39	1	Dial	<b>Miscellaneous</b>		
407-24	1	100 $\mu$ A meter	261-1	4	Rubber feet
453-7	1	Insulated shaft extension	340-2	1	length Bare wire
<b>Sheet Metal Parts</b>			436-4	1	Jack
90-28	1	Cabinet	427-2	4	Binding post base
203-52F65	1	Panel	595-79	1	Manual
204-M60	1	Bracket front			
204-M61	1	Bracket back			