



SAFETY NOTICE

Operation of this equipment involves the use of high voltages which are dangerous to life. Be very careful when working with this equipment.

ESSENTIAL DIFFERENCES BETWEEN BC-325-B and BC-325-C:

- (1) Fuses have been replaced by magnetic circuit breakers.
- (2) Thermostat used in oscillator and rectifier compartments are of an adjustable type.
- (3) Phenolic Crystal Holders FT-171-B are used.
- (4) An additional factory-adjusted trimmer capacitor has been added in the oscillator circuit. These changes are incorporated in the BC-325-C.