

Action/Chamber Tool Cleaning Set

Caution:

Always make sure gun is unloaded before cleaning!
Remember to protect stock finish from solvents.

Action Cleaning Tool Instructions

1. Insert swab into tool by rolling middle of swab into the slot provided. See Fig. 1.
2. Remove bolt. Insert swab fully into action and rotate to clean. Keeping swab horizontal during insertion and extraction will clean the bolt slide areas. See Fig. 2.

Chamber Cleaning Tool

1. Attach the correct size Chamber Mop (8 - 32 thread) into Chamber Cleaning Tool. See Fig. 3.
2. Apply degreaser to Mop.
3. Insert into chamber through breech end of action and rotate in chamber to remove oil and powder residue. The degreaser will evaporate rapidly, leaving chamber clean and dry.

Nylon Bristle Brush

Use to clean the bolt face and the Locking Lug surfaces. See Fig. 4.

Note: Be sure to lubricate the bolt locking lugs and bolt slide areas before shooting.




FIG. 1




FIG. 2



FIG. 3




FIG. 4