

- Engine & Cooling
- Fuel
- Ignition
- Electrical
- Running gear
- Torque settings
- Capacities
- Notes & Illustrations



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU **HELP**

Engine and cooling system 318iS & ti Compact (E36) 1992 to 1996

Type		M42/B18 18 4S1 16V 100kW
Capacity (cm ³) / number of cylinders		1796 / 4
Compression ratio / pressure	bar	10.0 / ≥10.0
Oil pressure	bar	1.3 to 2.0 [4.0 to 4.3]
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		TCE
Thermostat opening temperature	°C	88
Radiator cap pressure	bar	1.4±0.2

Fuel system 318iS & ti Compact (E36) 1992 to 1996

Idle speed - manual [auto]	rpm	850±40
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.5 N/A
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	—
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		Bosch
Type / ref		M1.7-Motronic
Main jet / needle		—
Injection pressure	bar	2.3 to 2.7
Pump pressure	bar	3.0±0.06
Octane rating	RON	95[U]

Ignition system 318iS & ti Compact (E36) 1992 to 1996

Type		Direct electronic
Ignition coil		Bosch
Primary resistance	ohms	0.8±0.1
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		—
Points gap (air gap)	mm	[0.30 to 0.70]
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		Clockwise
Ignition timing - basic [static	° Crankshaft @ rpm	Computer control N/A
V = Vacuum NV = No Vacuum		—
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		Bosch/NGK
Type		F7LDCR / BKR6EK
Electrode gap	mm	0.90-0.10

Electrical system 318iS & ti Compact (E36) 1992 to 1996

Battery	V / CC / RC	12 / 46 or 50Ah
Alternator voltage / full load current / engine rpm		13.5 to 14.2 / 65,70,80 / 1500
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear 318iS & ti Compact (E36) 1992 to 1996

Brakes -		
Front (min. friction material thickness)	mm	2.0
Rear (min. friction material thickness)	mm	2.0

Tyres		
Saloon	Size	185/65x15: 205/60x15
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	2.0 / 2.2. 205/60: 1.8 / 2.0
- Estate / Van	bar	—

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	[+18'±5']. Compact: [+18'±8']
Camber		-40'±30'. Sport: -58'±30' L ¹
Castor		+3°52'±30'. Sport: +3°57'±30'L
King pin inclination		+15°44'±30'. Sport: +15°56'

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	[+24'±6']. Compact: [+30'±13']
Camber		-1°40'±15' ²

Torque wrench settings 318iS & ti Compact (E36) 1992 to 1996


Cylinder head - stage 1	Nm	30 N
- stage 2	Nm	+ 90°
Cylinder head - stage 3	Nm	+ 90°
- stage 4	Nm	—
Big-end bearings	Nm	20 + 70° N
Main bearings	Nm	20 + 50° N
Clutch cover	Nm	24. 10.9 hex: 35
Flywheel [driveplate]	Nm	120 N
Front hubs	Nm	290
Rear hubs	Nm	300. Compact: 200
Wheel nuts / bolts	Nm	100±10
Spark plugs	Nm	30 to 33

Capacities 318iS & ti Compact (E36) 1992 to 1996

Engine oil & filter	litres	5.0
Gearbox - 4-speed [5-speed]	litres	1.0
Automatic transmission - refill	litres	3.0
Final drive	litres	1.1
Cooling system	litres	6.5
Fuel tank	litres	65. Compact: 52

Notes and Illustrations

¹Compact: -30'±30'
²Sport: -2°±15'. Compact: -2°±30'



1796 cm³, 16V