

Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system Ibiza 1.2i CAT 1991 to 1993

Type		021 A.1000 52kW
Capacity (cm ³) / number of cylinders		1193 / 4
Compression ratio / pressure	bar	10.8 / ≥11.5
Oil pressure	bar	≥1.5 [3.5 to 4.0]
Oil temperature	°C	100
Valve clearance - inlet	mm	0: Hyd.
- exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	88±2
Radiator cap pressure	bar	0.98

Fuel system Ibiza 1.2i CAT 1991 to 1993

Idle speed - manual [auto]	rpm	850±50
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	0.3 to 0.7
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	—
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		_Bosch
Type / ref		LU2-Jetronic
Main jet / needle		—
Injection pressure	bar	—
Pump pressure	bar	—
Octane rating	RON	95[U]

Ignition system Ibiza 1.2i CAT 1991 to 1993

Type		TSZ
Ignition coil		Bosch. Marelli. TZ18H
Primary resistance	ohms	0.6 to 1.0
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	10.0
Distributor		Bosch/_
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		Anticlockwise
Ignition timing - basic [static	° Crankshaft @ rpm	10 BTDC @ 850±50
V = Vacuum NV = No Vacuum		—
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		Bosch/NGK
Type		F5DC / BCP7ES
Electrode gap	mm	0.80 to 0.90

Electrical system Ibiza 1.2i CAT 1991 to 1993

Battery	V / CC / RC	12 / 45Ah
Alternator voltage / full load current / engine rpm		14.0 / 65 / 3000
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	340 / 7.0

Running gear Ibiza 1.2i CAT 1991 to 1993

Brakes -		
Front (min. friction material thickness)	mm	1.5
Rear (min. friction material thickness)	mm	1.5

Tyres		
Saloon	Size	155x13: 165/65x14
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	2.0 / 1.9
- Estate / Van	bar	—

Front suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	+2.0 to 4.0
Camber		-15' to -1°15'
Castor		0 to +1°45'
King pin inclination		—

Rear suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	+2.0 to 6.0
Camber		+51' to 1°51'

Torque wrench settings Ibiza 1.2i CAT 1991 to 1993



Cylinder head - stage 1	Nm	20 ¹
- stage 2	Nm	+ 90° ¹
- stage 3	Nm	+ 90° ¹
- stage 4	Nm	—
Big-end bearings	Nm	30 + 90°
Main bearings	Nm	85±5
Clutch cover	Nm	30
Flywheel [driveplate]	Nm	85
Front hubs	Nm	216
Rear hubs	Nm	216
Wheel nuts / bolts	Nm	Alloy: 78. Steel: 86
Spark plugs	Nm	32

Capacities Ibiza 1.2i CAT 1991 to 1993

Engine oil & filter	litres	4.1
Gearbox - 4-speed [5-speed]	litres	3.4
Automatic transmission - refill	litres	—
Final drive	litres	WT
Cooling system	litres	7.5
Fuel tank	litres	47

Notes and Illustrations

¹Bolts 1 to 10 only. Finally tighten bolts 11 & 12 to 20 only

1193 cm³1193 cm³